

Document Serial No. ....

Holder .....

Advantech Job No. ....

## **INTRAC™-605**

**INTELLIGENT TRACKING ANTENNA CONTROL UNIT**

**INCORPORATING CSO**


# **INSTALLATION & USER MANUAL**

**Issue 4**



Advantech Wireless Inc.  
39 Edison Road  
St Ives  
Huntingdon  
Cambs. PE27 3LF  
England

 UK General Enquiries 01480 357600

 International General Enquiries + 44 1480 357600

**Fax** UK 01480 357601 International + 44 1480 357601

**E-mail** [support.europe@advantechwireless.com](mailto:support.europe@advantechwireless.com)

**Website** <http://www.advantechwireless.com>

The copyright of this document is vested in Advantech AMT Limited and the document is issued in confidence for the purpose only for which it is supplied. It must not be reproduced, in whole or in part, or used for tendering or manufacturing purposes or disclosed to a third party except with the written consent of Advantech AMT Limited. Advantech AMT Limited is a wholly owned operating company of Advantech Wireless Inc.



## PREFACE

This equipment manual provides user/operational and installation information on the Advantech AMT Limited INTRAC-605 Satellite Tracking Antenna Controller.

### MANUAL SECTIONS :-

<a href="#"><u>Introducing the INTRAC-605</u></a>	An overview of the INTRAC-605 and INTRAC-605 basic systems.
<a href="#"><u>Safety</u></a>	Safe usage of the INTRAC-605.
<a href="#"><u>Specification &amp; Options</u></a>	The supplied specification, the fitted options and the available options.
<a href="#"><u>Operating the INTRAC-605</u></a>	How to use and operate the INTRAC-605.
<a href="#"><u>Alarms</u></a>	A description of the alarm conditions which can occur.
<a href="#"><u>Technical Description</u></a>	A technical description of the operation of the INTRAC-605.
<a href="#"><u>Installation &amp; Connections</u></a>	How to install and set-up an INTRAC-605 system, including information on the external connections to the INTRAC-605.
<a href="#"><u>Fault Finding</u></a>	Assistance in finding any faults which may arise.
<a href="#"><u>Warranty and Repair Information</u></a>	Warranty and repair service provided by Advantech AMT Limited.
<a href="#"><u>Remote Control Terminal</u></a>	Installing and using the RCM-4 Remote Control Terminal.

## CONTENTS

<b>PREFACE .....</b>	<b>i</b>
<b>CONTENTS .....</b>	<b>ii</b>
<b>LIST OF FIGURES.....</b>	<b>vi</b>
<b>LIST OF TABLES .....</b>	<b>vii</b>
<b>1. INTRODUCING THE INTRAC-605 .....</b>	<b>1</b>
A Typical System .....	2
<i>Retro Fitting</i> .....	2
<i>Antenna Drive</i> .....	3
<b>2. SAFETY .....</b>	<b>5</b>
Electrical .....	5
<i>Fusing</i> .....	5
<i>Earthing</i> .....	5
<i>Battery Disposal</i> .....	5
<i>RF I/P Connector for IBR-L</i> .....	5
<i>Emergency Stop</i> .....	5
Mechanical .....	5
<i>Mounting</i> .....	5
<b>3. SPECIFICATION &amp; OPTIONS.....</b>	<b>7</b>
Specification .....	7
Options .....	9
Delivered Configuration & Set-up .....	13
<b>4. OPERATING THE INTRAC-605.....</b>	<b>15</b>
Front Panel.....	15
The Menu Structure .....	16
The Menu Screen.....	16
Alphabetical Index of Menus .....	18
The Menus .....	20
<i>Home</i> .....	20
<i>Standby</i> .....	21
<i>New Mode</i> .....	22
<i>Manual/Stow</i> .....	23
<i>GOTO (Position)</i> .....	24
<i>Search</i> .....	25
<i>GOTO Satellite</i> .....	26
<i>Auto Continue</i> .....	27
<i>Auto New Model</i> .....	28
<i>Function (Configuration)</i> .....	29
<i>Beacon Pol Select</i> .....	30
<i>Beacon Frequency</i> .....	31
<i>Edit Satellite Table</i> .....	32
<i>Soft Limits</i> .....	33
<i>Extended Azimuth Setup</i> .....	34
<i>EG-01 Setup</i> .....	35
<i>Diagnostics On / Diagnostics Off</i> .....	36
<i>Continuous Servo Option</i> .....	37
<i>Beacon Threshold</i> .....	39
<i>Contrast &amp; Brightness</i> .....	40
<i>Fine Tune - Sense</i> .....	41
<i>Fine Tune - Offsets</i> .....	42
<i>Station Co-ordinates</i> .....	43
<i>Date &amp; Time</i> .....	44
<i>Time Rate Correction</i> .....	45
<i>AZ &amp; EL Beamwidth</i> .....	46

Stow Setup .....	47
Select Stow Use .....	48
Fitted Options .....	49
Geared POL .....	50
Rapid Model Generate .....	51
Program Track.....	52
Reserve Model .....	53
Edit IESS-412.....	54
Edit NORAD Buffer.....	55
Edit Star Track.....	56
Edit Satellite Table .....	57
Clear Models .....	58
Show Alarms .....	59
Remote/Local .....	60
Normal Operation.....	61
Manual Velocity Operation .....	62
<b>5. ALARMS &amp; ERRORS .....</b>	<b>65</b>
Primary Alarms.....	65
Secondary Alarms.....	66
Alarm Outputs .....	66
Recovering from Alarms .....	66
Power Failure .....	67
Errors .....	67
IESS-412 Data .....	67
<b>6. TECHNICAL DESCRIPTION.....</b>	<b>69</b>
The Tracking Algorithm .....	69
The Modes .....	72
Standby .....	72
Auto .....	72
Manual.....	73
Goto.....	74
Sleep .....	75
Remote .....	75
Using IESS-412 or NORAD Data.....	76
The IESS-412 data.....	76
NORAD Data.....	77
Rapid Model Generation .....	78
Program Track .....	79
Reserve Model .....	79
Clear Models .....	79
Antenna Motion Limits .....	79
Soft Limits.....	80
Hard Limits .....	80
Low Angle Switch .....	80
Axes Position .....	80
Tracking Signal .....	80
Velocity Drive .....	81
Redundancy Unit.....	83
Introduction.....	83
Connections.....	83
Removing one INTRAC from the Dual Redundant System .....	84
<b>7. CONNECTIONS &amp; SETUP .....</b>	<b>85</b>
Introduction .....	85
Rear Panel Layout .....	86
Connector Pin Allocations.....	87
Az & El Resolvers.....	87
Limits The cable for the Limits connection should comprise twisted pair cable with an overall screen..	88
Motor Control.....	89
Alarms .....	90

Aux 1.....	91
Aux 2.....	92
Aux 3.....	93
Serial Ports.....	94
Serial Port RS422/423 Setting.....	96
Serial Port Usage.....	96
Tracking Signal Connections.....	97
CSO Drive Outputs.....	97
Resolvers.....	98
Fitting to the Antenna.....	98
Setting up.....	98
Southern Hemisphere.....	99
Tracking Signal Input.....	99
With IBR-L.....	99
Without IBR-L.....	99
Operational Checks.....	100
Manual Operation.....	100
Emergency Stop Check.....	100
Auto Operation.....	101
Remote Control.....	101
<b>8. FAULT FINDING.....</b>	<b>103</b>
Introduction.....	103
Fault Symptoms.....	104
INTRAC Doesn't Appear To Power Up.....	104
Display Screen Blank/Dark.....	104
Replacing The LCD Backlight.....	105
Front Panel Keys Do Not Function.....	106
Emergency Stop Switch Fails.....	106
Pointing Angles Incorrect.....	106
No Antenna Drive.....	107
Tracking Signal (IBR-L).....	109
<b>9. WARRANTY &amp; REPAIR.....</b>	<b>111</b>
Warranty.....	111
Repair Service.....	111
<b>10. REMOTE CONTROL TERMINAL.....</b>	<b>113</b>
Introduction.....	113
Installation & Set-up.....	113
Installing the software.....	113
Configuring the RCM-4.....	114
Configuring the INTRAC.....	115
The RCM.INI file.....	116
Setting the Satellite Data.....	117
Setting Satellite name.....	117
Adding Satellites.....	118
Using The RCM-4.....	120
Alarms.....	121
Modes.....	121
Jog.....	121
Velocity.....	122
Goto Position.....	124
Auto Continue.....	124
Auto Initialise.....	124
Search.....	124
Function.....	125
RCM Config.....	125
INTRAC Config.....	126
Stow.....	126
Limits, Time & Frequency.....	127

Ephemeris Data.....	127
Valid Data Files.....	128
Nominal Position.....	128
IESS412.....	128
Transfer.....	128
NORAD.....	128
Add.....	129
Delete.....	129
Edit.....	129
Create/Edit Data File.....	130
Copy Ephemeris Data.....	130
Get Transfer Data.....	131
Load IESS Data.....	131
Load Transfer Data.....	131
Load NORAD Data.....	131
Move To.....	131
Goto Nominal Position.....	131
Generate Model from IESS Data.....	132
Generate Model from Transfer Data.....	132
Transfer Program Track.....	132
Generate Model from NORAD Data.....	132
NORAD Program Track.....	132
Standby.....	132
Return.....	132
The .ini file parameters.....	133
BeaconPolSelect.....	133
CSOEnable.....	133
ExtendedAz.....	134
newNamePromptEnable.....	134
<b>APPENDICES.....</b>	<b>135</b>

## LIST OF FIGURES

Figure 1 - A Typical System.....	2
Figure 2 - Intrac-605 Front Panel.....	15
Figure 3 – The Menu Structure.....	16
Figure 4 - The Menu Screen.....	17
Figure 5 - The HOME Menu .....	20
Figure 6 - The STANDBY Menu .....	21
Figure 7 - The NEW MODE Menu .....	22
Figure 8 - The MANUAL/STOW Menu .....	23
Figure 9 - The GOTO Menu.....	24
Figure 10 - The SEARCH Menu .....	25
Figure 11 - The GOTO SATELLITE Menu .....	26
Figure 12 - The AUTO CONTINUE Menu .....	27
Figure 13 - The AUTO NEW MODEL Menu.....	28
Figure 14 - The FUNCTION Menu.....	29
Figure 15 - The BEACON POL SELECT Menu.....	30
Figure 16 - The BEACON FREQUENCY Menu .....	31
Figure 17 - The EDIT SATELLITE TABLE Menu .....	32
Figure 18 - The SOFT LIMITS Menu .....	33
Figure 19 - The EXTENDED AZIMUTH SETUP Menu .....	34
Figure 20 - The EG-01 SETUP Menu.....	35
Figure 21 - The DIAGNOSTICS Menu .....	36
Figure 22 - The CONTINUOUS SERVO OPTION Menu .....	37
Figure 23 - The BEACON THRESHOLD Menu.....	39
Figure 24 - The CONTRAST & BRIGHTNESS Menu .....	40
Figure 25 - The FINE TUNE - SENSE Menu.....	41
Figure 26 - The FINE TUNE - OFFSETS Menu .....	42
Figure 27 - The STATION CO-ORDINATES Menu.....	43
Figure 28 - The DATE & TIME Menu .....	44
Figure 29 - The TIME RATE CORRECTION Menu.....	45
Figure 30 - The AZ & EL BEAMWIDTH Menu.....	46
Figure 31 - The SELECT STOW USE Menu.....	48
Figure 32 - The FITTED OPTIONS Menu .....	49
Figure 33 - The GEARED POL Menu.....	50
Figure 34 - The RAPID MODEL GENERATE Menu .....	51
Figure 35 - The PROGRAM TRACK Menu .....	52
Figure 36 - The RESERVE MODEL Menu .....	53
Figure 37 - The EDIT IESS-412 Menu .....	54
Figure 38 - The EDIT NORAD BUFFER Menu .....	55
Figure 39 - The EDIT STAR TRACK Menu .....	56
Figure 40 - The EDIT SATELLITE TABLE Menu .....	57
Figure 41 - The CLEAR MODELS Menu.....	58
Figure 42 - The SHOW ALARMS Menu .....	59
Figure 43 - The REMOTE/LOCAL Menu .....	60
Figure 44 - The Manual Mode Screen .....	82
Figure 45 - The Manual Velocity Screen .....	82
Figure 46 - The Position Hold Screen .....	83
Figure 47 - The Intrac Redundancy Switch .....	83
Figure 48 - The Connections Panel.....	84
Figure 49 - The Connections Block Diagram.....	85
Figure 50 - INTRAC-605 Rear Panel Layout.....	86
Figure 51 - Redundancy Unit Rear Panel Layout.....	86



## LIST OF TABLES

Table 1- Intrac-605 Options.....	9
Table 2 - Serial Port Connector & Link Positions .....	10
Table 3 - Position Encoders .....	11
Table 4 – Az/EI Resolver Cable Connections .....	87
Table 5 – Limits Cable Connections.....	88
Table 6 – Motor Control Cable Connections .....	89
Table 7 – Alarms Cable Connections .....	90
Table 8 – AUX 1 Connector.....	91
Table 9 – AUX 2 Connector.....	92
Table 10 – AUX 3 Connector.....	93
Table 11 – Serial Port Connections (RS423) .....	94
Table 12 – Serial Port Connections (RS422) .....	94
Table 13 – Serial Port Configuration (Connector & Link Positions) .....	96

Deliberately left blank

## 1. INTRODUCING THE INTRAC-605

The INTRAC-605 Intelligent Tracking Antenna Controller is a microprocessor based controller for tracking any nominally geostationary satellite including those at low elevation or with high angles of inclination. The tracking antenna is positioned on the satellite by a motor drive cabinet which is controlled by the INTRAC.

The INTRAC-605 builds a model of the satellite's orbit using a mathematical algorithm. To build the orbit model the INTRAC makes measurements by perturbing the antenna pointing angle very slightly and monitoring the change in received beacon signal strength. These small movements enable the INTRAC to estimate the position of the satellite and this estimate is used by the modelling algorithm.

The system always tracks the satellite from the model. The small movements of antenna pointing are used to maintain and update the model.


By using the model to point the antenna the INTRAC system ensures that the antenna is always pointed accurately at the satellite. This is in contrast to Step Track systems where the antenna spends most of the time not pointing at the satellite.

The regular measurements made by the INTRAC ensure that changes in the apparent orbit, due to station keeping manoeuvres or other causes, are identified. The model is modified and refined to incorporate these changes and accurate tracking is automatically maintained. The INTRAC will automatically increase the measuring rate if necessary in order to obtain sufficient information on the changing orbit.

As the INTRAC tracks using its orbit model it will continue to track the satellite if the tracking signal is degraded or lost. The satellite position may be accurately predicted from the model for up to 72hrs without a tracking signal.

The INTRAC system provides this exceptional tracking performance and robustness for satellites with any inclination, at any look angle, even in the presence of severe beacon signal degradation entirely automatically. No operator intervention or parameter setting is required when conditions or satellites are changed.

## A Typical System



**Figure 1 - A Typical System**

The antenna position resolvers provide direction information to the INTRAC. The IBR-L (beacon receiver) provides tracking signal strength. (A signal strength derived dc voltage from an external receiver may be used in place of the Advantech IBR-L)

The Motor Drive Cabinet receives the antenna drive commands from the INTRAC and drives the azimuth, elevation and polarisation (option) motors and brake assemblies.

Limit switches on the antenna prevent it from being moved beyond mechanically defined positions.

The INTRAC-605 may be controlled from its front panel or from an optional PC based Remote Control and Monitoring Terminal.

## Retro Fitting

Existing Step Track or Program Track installations may be updated to INTRAC-605 systems. Advantech AMT Limited. have considerable experience of retro fitting INTRAC systems.

### *Antenna Drive*

Antenna Azimuth and Elevation drive is by a pair of counter torqued motors on each axis. When the antenna is not being moved (other than in Standby mode) the power applied to each pair of motors is balanced to hold the antenna stationary. To move the antenna in any particular direction power is increased to one of the motors and reduced to the other. The motor with the increased power drives the antenna whilst the reduced power motor maintains countertorquing to eliminate backlash in the drive mechanism. Once the antenna has reached the required position both motors are again supplied with balanced power and the antenna maintains position. In Standby mode brakes are applied to hold the antenna stationary and drive to the motors is removed.

### *motor drive speed*

The speed at which the motors drive is continuously variable between 0°/sec and 0.3°/sec. In Goto, Search or Tracking modes the INTRAC ramps up the motor speed to a level dependant on the distance to be moved and ramps down towards the end of the move. In manual mode the speed can be ramped from the INTRAC front panel (the speed in degs/sec being displayed on the screen) or set directly, in degs per second, from a remote control terminal.

Deliberately left blank

## 2. SAFETY

### **WARNING**

#### **POSSIBLE LETHAL POTENTIALS EXIST WITHIN THIS EQUIPMENT**

THE COVERS SHOULD NOT BE REMOVED WHILST POWER IS APPLIED  
EXCEPT BY QUALIFIED PERSONNEL WHO ARE AWARE OF THE PRECAUTIONS  
THAT SHOULD BE TAKEN TO PROTECT AGAINST ELECTRIC SHOCKS

### **Electrical**

*Fusing* The unit is protected by a fuse in the live/phase (fase) power supply line.

Care should be taken to ensure that the power cable is correctly connected to the power source such that the live/phase connection of the INTRAC is connected to the live/phase terminal of the supply.

When replacing the fuse be sure to do so with one of the correct value and type.

*Earthing* It is important that the electrical supply has a good and proper earth and that earth is connected through to the INTRAC-605 via the power cable.

*Battery Disposal* The processor board contains a Nickel Cadmium (NiCd) or Lithium battery. These elements are toxic. The battery should be disposed of according to national requirements. DO NOT PLACE IN NORMAL GARBAGE OR IN A FIRE.

*RF I/P Connector for IBR-L* 18Vdc may be present on the inner of the N-Type connector to power the LNB/BDC. This voltage can be removed by unplugging connector J41.

*Emergency Stop* There is a latching emergency stop switch on the INTRAC front panel. Pressing this switch will remove power from the antenna drive motors and the INTRAC will enter Standby mode. To restore drive the switch should be rotated clockwise (CW) and Auto Continue selected.

Facilities exist at the Motor Drive Cabinet for the connection of external emergency stop switches. It is highly recommended that those fitted be of the latching type.

### **Mechanical**

*Mounting* The INTRAC-605 must not be mounted so that it is supported only by the front panel. A proper rack mounting kit must be used. This may be either of the fixed mounting type or the sliding rail type.

Deliberately left blank



### 3. SPECIFICATION & OPTIONS

The following pages contain the specification of the INTRAC-605, a list and description of the available options and a chart of the delivered configuration.

#### Specification

<i>Tracking Accuracy</i>	Typically <0.05dB RMS signal degradation after tracking for 30minutes (with tracking signal).
<i>Prediction Accuracy</i>	Typically <0.05dB RMS signal degradation over 72hrs (after loss of tracking signal).
<i>Tracking Signal</i>	May be derived from an external tracking receiver or from the (optional) Integral Beacon Receiver (IBR-L).
<i>External</i>	DC voltage varying directly with received signal strength (in dB). Scale factors between 0.1V/dB and 1.0V/dB can be preset with up to $\pm 10V$ offset.
	Lost Lock Input - Input for clean contacts - standard closed when tracking receiver lock is lost - opposite sense may be selected. Required contact rating 30V at 20mA.
<i>Internal</i>	Internal IBR-L requires an L-band signal with a level in the range -80dBm to -45dBm and C/No >40dB. Stability better than $\pm 150KHz$ . The received frequency is selected from the INTRAC front panel. The signal voltage and lock lost indicators are generated internally.
<i>Antenna Position Encoders</i>	Single or dual resolver units. Operating frequency is 800Hz nominal.
<i>RE-01</i>	Single resolver unit suitable for antennas with beamwidths greater than $0.4^\circ$ .
<i>EG-01</i>	Single resolver units suitable for antennas with beamwidths greater than $0.3^\circ$ .
<i>HD-001</i>	Electrically geared dual resolver units suitable for antennas with beamwidths from $0.06^\circ$ . They are particularly recommended for beamwidths below $0.3^\circ$ . They are limited motion transducers and are not suitable for antennas with a rotation range of greater than $340^\circ$ .
<i>Special</i>	On large antennas special, antenna specific, pointing angle measurement solutions may be used.

<i>Position Offset</i>	The indicated pointing angles can be electrically offset in all axes to an accuracy of 0.01° to compensate for angular mounting offset in the position encoders.
<i>Limit Switches</i>	Inputs for antenna movement limit switches in all three axes. These limit switches should be closed when the antenna is within limits. Contacts rated at 30V 100mA.
<i>Back-up</i>	Time is maintained by a battery backed clock. Operating parameters, data and orbital models are held in EEPROM.
<i>Outputs</i>	Antenna drive. Emergency Stop contacts. Alarm contacts.
<i>Dimensions</i>	483mm Wide x 132mm High x 406mm Deep. (19" rack x 3U).
<i>Mounting</i>	Standard 19" rack mounts or rails. <b>DO NOT MOUNT BY FRONT PANEL LUGS ALONE</b> <b>THE UNIT MUST BE SUPPORTED ALONG ITS SIDES.</b>
<i>Weight</i>	12kg (without IRB-L). 15kg (with IRB-L).
<i>Operating Temperature</i>	0°C - 40°C.
<i>Relative Humidity</i>	10% - 90% non-condensing.
<i>Power</i>	220V - 240V 50Hz 50W. 110V - 120V 60Hz 50W.
<i>Country of Origin</i>	United Kingdom.

## Options

The following table shows the options available with the INTRAC-605.

The options are described in the following pages. At the end of this section is a table showing the configuration of the INTRAC-605 to which this manual corresponds.

A “●” alongside an option indicates that a change or addition is required. Any option with a “●” in the first column can be selected from the “Fitted Options” menu except for those two which require changes to the INTRAC firmware. However most of them also require changes or additions to the system hardware.

Voltage and Serial Interfaces only need a change to switch and / or connector positions within the INTRAC.

OPTION	REQUIRES SET-UP CHANGES OR ADDITIONS TO :-			
	FRONT PANEL MENU SELECTIONS	Advantech / 3rd PARTY SYSTEM HARDWARE	INTRAC-605 FIRMWARE	INTRAC-605 HARDWARE
Voltage				●
Serial Interfaces				●
IBR-L Beacon Receiver	●			●
Inv Beacon Lock - Loss of Input	●			
Polarisation	●	●		
Mount Type	●	●		
Az/EI Resolver Type	●	●		
Opto Encoders	●	●	●	●
Extended Azimuth	●	●		
Geared Polarisation	●	●		
Simultaneous Axis Drive (SimAx)	●	●		
Continuous Servo Option (CSO)	●	●	●	●
Redundancy Switching		●	●	●
Stow Option	●	●		

**Table 1- Intrac-605 Options**

*Voltage*

The power supply unit of the INTRAC-605 is switchable between 220Vac and 110Vac. The switch is located on the rear panel next to the power lead receptacle. Ensure that the switch is in the correct position before switching the unit on.

*Serial Interfaces*

There are three serial ports on the INTRAC-605 which can be independently set to either RS423 or RS422. This selection can be done by the user. It involves connecting the rear panel connectors to the appropriate connectors on the main board and setting the option links as shown below.

<b>Serial Port Configuration - Connector and Link Positions</b>				
Port Designation	RS423		RS422	
	Ribbon Cable Position	Link Position	Ribbon Cable Position	Link Position
Remote Control Port	J13	J48 Front	J16	J48 Rear
Test Port 1	J12	J44 Front	J15	J44 Rear
Test Port 2	J11	J46 Front	J14	J46 Rear

**Table 2 - Serial Port Connector & Link Positions**

*IBR-L Beacon Receiver*

The INTRAC-605 can be supplied fitted with an L-band beacon receiver or the user can supply a tracking signal voltage which varies directly with the received signal strength in dB.

*Inv. Beacon Lock*

If an external receiver is used to provide the tracking signal a beacon lock input is available to indicate to the INTRAC that the tracking signal receiver is in lock. Normally an open circuit is required to indicate lock. However if "Inv. Beacon Lock" is enabled a short circuit indicates lock.

*Polarisation*

If the antenna has motorised polarisation the INTRAC can be configured to control the polarisation angle. The polarisation resolver may be direct drive or geared drive refer to "Geared Polarisation" on the next page.

*Mount Type*

Two types of antenna mount may be used with the INTRAC. An Az/EI mount or a Polar mount. The appropriate one is selected in "Fitted Options" as AZ/EI or Hr-Ang/Declination.

**Resolver Type**

Various types of resolver may be used to provide the pointing angle data to the INTRAC. The applicable type is set in "Fitted Options".

Advantech AMT Limited primarily provide three types of resolver for Azimuth and Elevation with the specifications below :-

<b>POSITION ENCODERS</b>			
	<b>RE-01</b>	<b>EG-01</b>	<b>HD-001</b>
RESOLUTION	16 bit	17 bit	19 bit
BACKLASH	< 0.5 Minutes	< 0.5 Minutes	NEGLIGIBLE
RMS ACCURACY	0.04°	0.02°	0.018°
GEARING RATIO	1 : 1	1 : 2	1:8 (electrical) & 1:1
SUITABILITY FOR ANTENNA 3db BEAMWIDTH	0.4° upwards	0.3° upwards	0.12° upwards
RECOMMENDED CABLE I/F	3 Twisted pair individually screened	3 Twisted pair individually screened	6 Twisted pair individually screened
ANTENNA POINTING DISPLAY RESOLUTION	0.01°	0.01°	0.001°
WEATHER PROOFING	IP66	IP66	IP66
ROTATION LIMITS	None	None	340°
MOUNTING	3.5" Synchro Case	3.5" Synchro Case	3.5" Synchro Case

**Table 3 - Position Encoders**

When the Polarisation facility is fitted a Polarisation resolver is also required. The INTRAC Polarisation resolver interface is suitable for either the RE-01 or a size 11 bare resolver.

The size 11 resolver has a similar specification to the RE-01 except in its accuracy and as it is not weatherproof the mounting and its size are different.

A weatherproof version of the size 11 is available to special order.

<i>Extended Azimuth</i>	Some antennas can rotate through more than 360°. In such a case the INTRAC needs to know which revolution the antenna is in. Extended Azimuth is selected in "Fitted Options".
<i>Geared Polarisation</i>	Position resolvers are normally coupled 1:1 to the rotational shaft. However for polarisation the resolver may be connected through gearing to the rotating shaft. In such a situation the INTRAC needs to know the gearing ratio. Geared Pol is set as fitted in "Fitted Options" and the ratio selected in "Geared Polarisation".
<i>Simultaneous Axis Drive</i>	Drive to the Azimuth & Elevation motors may be on an either/or basis or both simultaneously. The selection of "SimAx Drive" is in the "Fitted Options" menu. However SimAx requires a different Motor Controller to the standard drive which must be specified at time of order.
<i>Continuous Servo</i>	Antennas with dual motor (per axis) continuous torque drives may require a continuous servo system. The Continuous Servo option provides a continuous velocity demand output to control a velocity demand servo. This option requires CS option software in the INTRAC-605 which should be specified at time of order.
<i>Redundancy Switch Unit</i>	The Redundancy Switch Unit links two INTRACs together in a dual redundant system. In the event of a fault occurring on the current Master unit the system automatically switches the other unit on line so that tracking continues unaffected.
<i>Stow Option</i>	<p>There is provision in the INTRAC-605 configuration for Az/EI preliminary and final stow positions to be set.</p> <p>The "Stow" command causes the antenna to be driven to the preliminary position in both axes. Once at this position the antenna is driven to the final position. For systems which have the appropriate stow pin drive facility the stow pin(s) are then driven in.</p> <p>The "Unstow" command causes the pin(s) to be removed (where appropriate) and the antenna driven to the preliminary position.</p> <p>The preliminary and/or final positions can be set to "not-used" for one or both axes.</p>

**Delivered Configuration & Set-up**

Voltage  
 Serial Interface  
 IBR-L Beacon Receiver  
 Inv Beacon Lock  
 Mount Type  
 Motorised Polarisation  
 Resolver Type  
 Extended Az  
 Geared Pol  
 Simultaneous Axis Drive  
 Continuous Servo Option  
 Redundancy Switch Unit  
 Stow Option

Yes  
 Yes

Beacon Receiver band  
 Beacon frequency  
 Beacon Threshold  
 Soft Limits

dB  
 Az  
 EI  
 CCW  
 Down  
 CW  
 Up

CSO Configuration

Direct Gain

Az  
 EI

Integrator Gain

Az Rt  
 EI Up  
 Az Lt  
 EI Dn

Parameters

1:  
 Option 1:  
 Option 2:  
 Option 3:  
 Option 4:  
 2:

System Setup

Contrast 08 Brightness 07 Flicker 02

Fine Tune Sense Az EI  
 Fine Tune Offset Az EI

Station Co-ordinates

Lat  
 Long  
 Height

Antenna Beamwidth

Az EI

Stow Setup

Final Az EI  
 Prelim Az EI

Stow Use

Final Az EI  
 Prelim Az EI

Fitted Options	Beacon Receiver
	Pol Sel A/B
	Polarization
	Mount Az/EI
	Type HrAng/Dcl
	Resolver EG-01
	Type RE-01
	HD-001
	Extended Az
	Geared Pol
	SimAx Drive
	Inv Beacon Lock




## 4. OPERATING THE INTRAC-605

The INTRAC-605 may be operated directly from the front panel or from the (optional) Remote Control and Monitoring Terminal.

For both methods of operating a series of menus enables a user to program the INTRAC and to invoke its modes of operation.

Operation from the front panel is described in this section of the manual. The (optional) remote terminal (the RCM-4) is described in an attached Appendix (see Appendices Contents).

### Front Panel



**Figure 2 - Intrac-605 Front Panel**

#### LCD Display Panel

This displays the current status of the INTRAC-605 and the selected menu which includes the labels for the menu keys.

#### Menu Keys

These six keys have functions dependant on the selected menu. The right side of the menu display indicates the function of each key for that menu.

#### Numeric Keypad

The keypad is used to enter or edit data into the INTRAC. The ← & → keys move the cursor left and right. The +/- key is used to change the sign or, in some cases to insert a space character.

#### Manual Control Keys

For manual control of the antenna pointing when the INTRAC is in manual mode.

#### System Alarm Indicator

Illuminates when a primary alarm occurs and remains on until the cause of the alarm is cleared.

Note.

#### Emergency Stop Button


An active primary alarm disables antenna drive. Pressing the button removes all drive from the antenna. The button locks in the safe position when pressed. To enable

drive to return to the antenna the button must be rotated clockwise until it releases.

#### On/Off Switch

Illuminated rocker switch to apply power to the INTRAC-605. Illuminated when the INTRAC is on.

### The Menu Structure



**Figure 3 – The Menu Structure**

The diagram above shows the various menus in a “tree” structure.


The menu headings in heavy type are selected by the six menu keys from the “HOME” menu. The headings in the box below “NEW MODE” are selected by the menu keys in NEW MODE. The shaded area headings are sub menus of the MODELS, CONFIGURATION and SYSTEM SETUP menus. They are accessed by using the “Next Field” menu key from the appropriate menu followed by the “ENTER” key on the numeric keypad.

#### Example

To select “STOW SETUP” from the HOME menu :-

FUNCTION	(menu key)
SYSTEM SETUP	(menu key)
NEXT FIELD	(menu key) press five times.
ENTER	(numeric keypad)

### The Menu Screen



**Figure 4 - The Menu Screen**

A typical menu display screen is shown above. In this example it is the “Goto Position” used to drive the antenna to a particular pointing angle.

The top section shows the current mode of the INTRAC, whether the control is remote or local and the various pointing angles of the antenna.

**Note** On some screens (e.g., HOME) the current status display expands to fill the lower part of the screen.

Down the right side of the screen are the current functions of the six menu keys.

Above the key labels is the menu type designator, i.e., one of the six main menu headings.

The main part of the display relates to the selected menu.

The individual menus are described on the following pages in order of the menu tree shown above. The order is from left to right and taking the branches as they come.

On the next page is an alphabetical index of the menus to assist in the quick location of a specific function.

**Alphabetical Index of Menus**

Alarms .....	59
Auto Continue .....	27
Auto New Model .....	28
Az & El Beamwidth .....	46
Beacon Pol Select .....	30
Beacon Frequency .....	31
Beacon Threshold .....	39
Beamwidth Az & El .....	46
Brightness & Contrast .....	40
Clear Models .....	58
Configuration .....	29
Continuous Servo .....	37
Contrast & Brightness .....	40
Date & Time Setting .....	44
Diagnostics On/Off .....	36
Edit IESS-412 .....	54
Edit NORAD .....	55
Edit Satellite Table .....	57
Edit Star Track .....	56
EG-01 Setup .....	35
Extended Azimuth .....	34
Fine Tune Offsets .....	42
Fine Tune Sense .....	41
Fitted Options .....	49
Function .....	29
Geared Polarisation .....	50

Goto Position	24
Goto Satellite	26
Home	20
IESS-412 Edit	54
Local/Remote	60
Manual/Stow	23
Manual Velocity	62
Models	51 to 58
New Mode	22
NORAD Edit	55
Program Track	52
Rapid Model Generate	51
Remote/Local	60
Reserve Model	53
Satellite Table Edit	32
Search	25
Select Stow Use	48
Show Alarms	59
Standby	21
Star Track Edit	56
Station Co-ordinates	43
Soft Limits	33
Stow	23
Stow Set-up	47
System Set-up	40 to 50
Time Rate Correction	45
Time Setting	44

The Menus

Home





Figure 5 - The HOME Menu

Path	HOME
Note	This menu can be reached directly from <b>almost</b> every menu by pressing Menu Key 2.
Description	<p>This is the root Menu as shown in the menu structure diagram on page 16.</p> <p>It is from here that the five main menus are accessed directly by use of the Menu Keys.</p>

*Standby***Figure 6 - The STANDBY Menu**

Path	STANDBY
Note	This menu can be reached directly from <b>almost</b> every menu by pressing Menu Key 1.
Description	<p>Standby is a monitoring but no movement mode. The antenna is not driven in this mode but its position and the beacon signal strength are monitored and displayed. External inputs are also monitored and any appropriate alarm(s) become active. The System Alarm indicator will illuminate and the alarms may be viewed by pressing "Show Alarms".</p> <p>Standby mode is entered in one of three ways :-</p> <ul style="list-style-type: none"> <li>— by being selected by the operator using Menu Key 1.</li> <li>— by a primary alarm becoming active.</li> <li>— at the end of a Goto move or at the end of a search.</li> </ul>

New Mode




Figure 7 - The NEW MODE Menu

Path	Menu key 3 from the “HOME” or “STANDBY” menus.
Description	<p>Displays the current mode and antenna pointing angles on the full screen.</p> <p>This is the entry menu for moving the antenna.</p> <p>Menu key 3 leads to the Manual antenna control and antenna stow menu.</p> <p>Menu key 4 leads to the “Goto” menu for “Goto Position”, “Goto Satellite” and “Search”.</p> <p>Menu key 5 resumes tracking using the current model. (Assuming that there is a valid model).</p> <p>Menu key 6 clears the existing model and starts learning a new model for the satellite at the current pointing.</p>



## Manual/Stow




Figure 8 - The MANUAL/STOW Menu

Path HOME - NEW MODE - MENU KEY 3

## Description

## Manual

This menu screen enables the antenna pointing direction to be changed manually by use of the Manual Control Keys on the front panel. Menu key 5 enables either azimuth & elevation or the polarisation motors to be driven.

Azimuth is driven by the left and right manual keys. Elevation is driven by the upper and lower manual keys. Polarisation is driven by the left (ccw) and right (cw) manual keys.

Menu key 6 latches which ever manual key is pressed and drives at an increased speed. (Useful for large distance moves) Pressing key 6 again releases the latching effect.

Menu key 3 selects Manual Velocity drive. See page 62 for a description of Manual Velocity drive.

## Stow

Menu key 4 (alternate functions) causes the antenna to be driven to the pre-set stow position (via the preliminary stow position) and, where appropriate, the stow pins to be driven into locking position.

If the antenna is "stowed" key 4 causes the stow pins to be withdrawn, where appropriate, and the antenna to drive to the preliminary stow position. (see Stow Setup)

## Notes

The Drive Fail alarm does not work in Manual (P) mode.

The antenna may be driven through azimuth 0° (North) in Manual (P) mode (azimuth 180° [South] in Southern Hemisphere).

Manual (P) mode is local (front panel) control as opposed to remote manual control which is Manual (A) Mode.

GOTO (Position)




Figure 9 - The GOTO Menu

Path

HOME - NEW MODE - MENU KEY 4

Note

Pressing menu key 4 (Goto) on the New Mode menu leads to the Goto Position (as opposed to Goto Satellite) menu. Goto Satellite and Search are accessed from this (Goto Position) menu by Menu Keys 5 and 4 respectively.

Description

Used to drive the antenna to the co-ordinates displayed.

The co-ordinates can be set by using menu key 6 (Next Field) to step through the three angles and the Beacon Frequency. The co-ordinate enclosed in the box can be edited from the numeric keypad. The ← & → keys are used to move the cursor to the desired character. The required position should be entered in true co-ordinates.

Pressing the ENTER key causes the antenna to commence driving to the set co-ordinates. When the antenna reaches the position the INTRAC enters STANDBY Mode.

## Search

Current Mode      Tracking		Mode	
Control State	Local	Standby	
Beac Freq	11.500000GHz	Home	
El Angle	25.55°	Goto Position	
Az Angle	235.45°		
Pol Angle	25.63°	Goto Satellite	
<b>SEARCH</b> <u>Nom. Angle</u> <u>Box Size</u> El    -027.334°      2.0° Az    178.550°      2.0° Dwell Time      25secs Beac Freq      12.250500GHz Press EN to begin search		Next Field	

1

*puts the antenna control system into STANDBY mode and skips to the HOME menu*

2

*skips to the Home (root) menu*

3

*skips to the Goto Position menu*

4

*(not used)*

5

*skips to the Goto Satellite menu*

6

*moves the highlight box to the next field in the current menu*

Figure 10 - The SEARCH Menu

## Path

HOME - NEW MODE - GOTO (Position) - MENU KEY 4

## Description

Used to search a specific area of sky for the strongest signal on the beacon frequency.

The antenna may be driven to the nominal co-ordinates of the required satellite by either the Goto Position or Goto Satellite commands or manually. Alternatively the Az & El true co-ordinates can be entered on this screen.

Using Menu Key 6 (Next Field) and the numeric keys the satellite's position and beacon frequency may be entered.

The search box size and the antenna dwell time are also entered in the same manner.

The box size parameters are either side of the nominal angle thus entering 2° will cause a 4° scan.

The dwell time is the time that the antenna will remain at each step. It is the lock time of the beacon receiver. For the IBR-L (The Advantech AMT supplied Integrated Beacon Receiver) the default dwell time of 25 seconds is correct.

Once all the co-ordinates are set pressing ENTER will start the search. The antenna will drive to the nearest corner of the search box before commencing the search pattern.

GOTO Satellite




Figure 11 - The GOTO SATELLITE Menu

Path HOME - NEW MODE - GOTO (Position) - MENU KEY 5

Description The INTRAC-605 can store the co-ordinates, polarisation angle and beacon frequency of 40 satellites. The co-ordinates should be true co-ordinates. With this screen the antenna can be driven to any satellite whose parameters have been stored.

When this screen is accessed the displayed parameters refer to the current satellite.

To move to a new satellite key in the required satellite's number using the numeric keypad. (Press Menu Key 6 to view the stored parameters if required)

Press ENTER and the antenna will drive to the new satellites co-ordinates. Select Home (Menu key 2) to leave this menu without moving to a new satellite.

If the satellite's parameters need to be changed Menu Key 5 switches to the Edit Satellite screen. For an explanation of that facility see "Edit Satellite Table".

Menu key 6 is used to view the data of a satellite after entering the "Number".

## Auto Continue




Figure 12 - The AUTO CONTINUE Menu

Path	HOME - NEW MODE - MENU KEY 5
Description	<p>This facility does not have a screen of its own. It is a function enabled by a menu key on the New Mode menu.</p> <p>If the INTRAC had been in Learning or Tracking mode and had been taken out of that mode, and the model was still valid, pressing Auto Continue will return the INTRAC to that mode.</p> <p>The antenna may have been stowed or moved off satellite for some other reason. Alternatively the INTRAC may have gone into Standby due to an alarm. In either case (once the antenna has been unstowed) pressing Auto Continue will cause the antenna to drive back to the satellite and continue Learning or Tracking.</p> <p>If the INTRAC had been Tracking but the time off satellite was too long for the model to be relied on it will restart in Learning mode to build a new model.</p>
Note	<p>Until and unless the orbit model is cleared pressing Auto Continue will cause the antenna to be driven to the satellite of that model. Thus if a new satellite is required to be tracked the antenna must be driven to that satellite's location and "Auto New Model" used to cause the INTRAC clear the existing model and start to build a new one. (see Auto New Model on the next page)</p>

Auto New Model




Figure 13 - The AUTO NEW MODEL Menu

Path HOME - NEW MODE - MENU KEY 6

Description This facility does not have a screen of its own. It is a function enabled by a menu key on the New Mode menu.

Auto New Model is used when it is required to track a new satellite. It causes the INTRAC to clear the existing model (if there is one) and start to build a new model of the orbit of the satellite whose beacon signal it is receiving.

Thus before pressing the Auto New Model key the antenna must be peaked on the required satellite's main transmission lobe. The peaking may be done in manual mode or automatically using Search Mode.

On pressing Auto New Model the INTRAC will enter Learning mode. After 24hrs of learning the orbit and building the model the INTRAC will enter Tracking mode.

## Function (Configuration)




Figure 14 - The FUNCTION Menu

## Path

HOME - MENU KEY 4

## Note

There are three separate menus under the FUNCTION heading. Pressing Menu Key 4 (FUNCTION) on the "Home" menu leads to the CONFIGURATION menu from which the MODELS menu and the SYSTEM SETUP menu are reached via Menu Keys 3 & 5 respectively.

This Configuration menu can also be reached by Menu Keys from the MODELS & SYSTEM SETUP menus

## Description

The Configuration menu contains seven sub menus plus Diagnostics On & Off.

The sub menus are described on the following pages.

The Diagnostics On & Off keys are used to route the INTRAC diagnostic data to the Remote Control port. This facility enables one PC to be used as both the remote control terminal and the diagnostics receiving terminal. However it cannot do both at the same time.

WHEN IT IS REQUIRED TO CONTROL THE INTRAC FROM THE REMOTE TERMINAL DIAGNOSTICS MUST BE SWITCHED OFF.

## Menu Key 4

Test Port - 1 Diags (Angles)

The data available at Test Port - 1 is either INTRAC diagnostic data (the same diagnostic data as mentioned above) or angles data. Selection between these two is by Menu Key 4 whose label toggles between "Diags" & "Angles"

Beacon Pol Select




Figure 15 - The BEACON POL SELECT Menu

Path HOME - FUNCTION - ENTER

Description This function is only applicable when an Advantech AMT supplied external L-band source switch is fitted. It allows the source of the beacon signal to be selected. The selection is from one of four sources.

Four LNBs may be fitted to the antenna at different polarisation angles or with different L.O. frequencies.

Note This facility is an option and requires extra hardware to function.

Beacon pol select must be set to “Fitted” in the System Setup - Fitted Options menu.

Pressing Menu Key 4 steps the selection through A - B - C - D and back to A.



## Beacon Frequency




Figure 16 - The BEACON FREQUENCY Menu

Path

HOME - FUNCTION - MENU KEY 6 - ENTER

Description

This function effects the tuning of the IBR-L (if fitted) to the beacon frequency of the satellite to be tracked.

The IBR-L operates over the frequency range 945MHz to 1.75GHz (L-band). A block down converter is required to convert the actual beacon frequency to the L-band range.

Note

The conversion from the operating frequency to the L-band frequency for the IBR-L is performed automatically for BDCs with standard local oscillator frequencies.

Setting Frequency

Menu Key 6 (Next Field) selects either the Frequency or Band No. for editing. The Band No. **must** be set first otherwise the frequency cannot be entered. Use the numeric keypad to overwrite the band number and/or frequency as required.

The down conversions assumed by the INTRAC-605 are :-

Band No.	Conversion
1	none
2	5.15GHz - C band
3	X band - 6.3GHz
4	Ku1 band - 10GHz
5	Ku2 band - 10.75GHz
6	Ku3 band - 11.475GHZ
7	Ku4 band - 11.3GHZ

Notes

Whilst bands 6 & 7 cover, in part, the same frequency range the down conversion frequency is different.

To use an X-band frequency below 7.25GHz an IBR-L with an extended low frequency range is required.

Edit Satellite Table





Figure 17 - The EDIT SATELLITE TABLE Menu

Path	HOME - FUNCTION - MENU KEY 6 (X2) - ENTER  or From Models or System Setup:- CONFIG - MENU KEY 6 (X2) - ENTER
Description	<p>The INTRAC-605 can store bearing parameters for 40 satellites.</p> <p>This function allows the editing of previously stored data and/or the addition of new data. Position information should be entered in true co-ordinates.</p> <p>Menu Key 6 steps the edit box through the six fields. Using the numeric keypad enter the satellite's parameters and the number it is to be stored under.</p> <p>Pressing ENTER sets the new values.</p> <p>Note 1 The Satellite Number must be between 1 and 40 inclusive.</p> <p>Note 2 If the frequency is between 12.55GHZ and 12.75GHZ ensure that the correct band number is set for the down converter frequency, i.e., band 6 or band 7. (see previous page - Beacon Frequency)</p> <p>To view the data relating to a satellite number use the Goto Satellite menu, page 26.</p>

## Soft Limits



**Figure 18 - The SOFT LIMITS Menu**

Path	HOME - FUNCTION - MENU KEY 6 (x3) - ENTER
or	From Models or System Setup :- CONFIG - MENU KEY 6 (x3) - ENTER
Description	Antenna movement limits may be programmed which will stop the antenna drive (and raise a primary alarm) if any one of them is reached.
Note 1	<b>These are software limits they do not physically break the drive circuits to the antenna motors.</b>
Note 2	DRIVE IN MANUAL MODE IS NOT INHIBITED BY THE SOFT LIMITS.
Note 3	Soft limit angles should be entered in true co-ordinates.
Setting	Menu Key 6 (Next Field) steps the edit box through the six fields. Data is overwritten with the numeric keypad. Pressing ENTER accepts all the fields.

Extended Azimuth Setup





Figure 19 - The EXTENDED AZIMUTH SETUP Menu

Path	HOME - FUNCTION - MENU KEY 6 (x4) - ENTER
	or From Models or System Setup :- CONFIG - MENU KEY 6 (x4) - ENTER
Note	This function is only available if “Extended Az” has been set to “Fitted” in the System Setup - Fitted Options Menu. (see page 49)
	If the “Resolver Type” in System Setup - Fitted Options has been set to “EG-01 Fitted” this line of the Configuration menu reads “EG-01 Setup”. (see next page)
Description	<p>For antennas which can be driven through more than 360° it is necessary for the INTRAC to “know” which revolution the antenna is in at any one time.</p> <p>When powered-up for the first time the INTRAC-605 assumes the first revolution. If the antenna is actually in the second revolution this function is used to add 360° to the displayed angle. The off-set state is stored in EEPROM so that it is preserved through power failures.</p>
Setting	Menu Keys 3 & 4 are used to set or clear the 360° offset. Key 3 sets (or adds) the offset. Key 4 clears a previously set offset.
Note	This function is only used during installation of, or when replacing, an INTRAC-605 unit.

**EG-01 Setup****Figure 20 - The EG-01 SETUP Menu**

Path	HOME - FUNCTION - MENU KEY 6 (x4) - ENTER
or	From Models or System Setup :- CONFIG - MENU KEY 6 (x4) - ENTER
Note	This function is only available if the “Resolver Type” in System Setup - Fitted Options has been set to “EG-01 Fitted”. If the “Extended Az” in System Setup - Fitted Options has been set to “Fitted” this line of the Configuration menu reads “Extended Azimuth Setup”. (see previous page)
Description	The EG-01 resolvers have a 1:2 gear ratio between the input shaft and the angle data output. This is in order to achieve higher resolution. However it means that the output moves through 720° for 360° of input rotation. Thus in Azimuth the INTRAC seeks to initially resolve this 180° ambiguity.

Diagnostics On / Diagnostics Off




Figure 21 - The DIAGNOSTICS Menu

Path HOME - FUNCTION - MENU KEY 6 (x5 for ON)  
(x6 for OFF) - ENTER

or From Models or System Setup  
CONFIG - MENU KEY 6 (x5 or 6) - ENTER

Description Diagnostics On & Off are used to route the INTRAC diagnostic data to the Remote Control port.

Use Menu Key 6 to step the highlight bar to the ON or OFF line and press ENTER to set.

Note This facility enables one PC to be used as both the remote control terminal and the diagnostics receiving terminal. However it cannot do both at the same time.

WHEN IT IS REQUIRED TO CONTROL THE INTRAC FROM THE REMOTE TERMINAL DIAGNOSTICS MUST BE SWITCHED OFF.

## Continuous Servo Option




Figure 22 - The CONTINUOUS SERVO OPTION Menu

Path	HOME - FUNCTION - MENU KEY 6 (x7) - ENTER
or	From Models or System Setup CONFIG - MENU KEY 6 (x7) - ENTER
Note	This facility is not available unless the Continuous Servo Option was ordered as part of the system
Description	<p>This menu is used to set the various parameters for the Continuous Servo Drive option.</p> <p>The parameters are decided empirically during the installation. Please refer to factory for advice if the installation will not be carried out by engineers from Advantech AMT Limited.</p>
Direct Gain	The first 2 numeric fields are the direct gain used by servo control loop. Typically the correct values are in the range from 1 to 10, although other values may be appropriate, depending on the characteristics of other components in the servo system. If the value is too low, then the response will be sluggish. If the value is too high then there will be a tendency for the antenna to overshoot and oscillation may occur.
Integrator Gain	The next 2 numeric fields are the integrator gain used by servo control loop. These ensure that the position loop has no permanent error. Typical values are in the range 0.01 to 0.1. The parameters should not be zero, but the lowest value that gives acceptable performance should be used.
Gain Modifier	The 2 numeric fields are the gain modifier used by servo control loop. A value of 0.1 in the Lt (Dn) field subtracts 1 (note this is 10x larger) from the direct gain when moving left (down).
Test Parameters	The final 2 numeric fields are test parameters. The CSO test mode commands both axes to drive in a square wave so that

the servo parameters can be set for optimum step response. Parameter 1 is the square wave amplitude and parameter 2 is the  $\frac{1}{2}$  period. When entering the test parameters the decimal point should be ignored and the number treated as an integer. A value of 0.0016 (ie the integer 16) for test parameter 1 gives an amplitude of  $16 * \text{LSB19} (16 * 0.0007 = 0.011 \text{ degrees})$ . A value 0.1024 (ie the integer 1024) gives a  $\frac{1}{2}$  period of  $1024 * 1/64 \text{ sec} (= 16 \text{ sec})$ . These parameters only have any effect when option 1 is fitted.

- |          |  |
|----------|--|
| Option 1 | When fitted option 1 enables the test mode described above whenever the INTRAC is in a node other than Standby. Should be <b>Not</b> fitted for normal operation.  |
| Option 2 | Should normally be <b>Not</b> Fitted. When fitted it Quenches all servo loop integrators when the antenna is close to the demanded position.   |
| Option 3 | When fitted the INTRAC monitors the actual velocity in Velocity mode and applies feedback to accurately provide the demanded velocity. It should be used when accurate manual velocity slew is required.               |
| Option 4 | When fitted this disables an acceleration limit on the velocity demand. The acceleration limit is not normally required as the drive units will incorporate such limits. Therefore the normal state is <b>Fitted</b> . |

#### Test Parameters

The values at installation were :-

CSO Configuration

Direct Gain	Az:	<input style="width: 95%;" type="text"/>
	El:	<input style="width: 95%;" type="text"/>
Integrator	Az Rt:	<input style="width: 95%;" type="text"/>
Gain	El Up:	<input style="width: 95%;" type="text"/>
	Az Lt:	<input style="width: 95%;" type="text"/>
	El Dn:	<input style="width: 95%;" type="text"/>

Parameters

1: <input style="width: 95%;" type="text"/>	2: <input style="width: 95%;" type="text"/>
Option 1: <input style="width: 95%;" type="text"/>	
Option 2: <input style="width: 95%;" type="text"/>	
Option 3: <input style="width: 95%;" type="text"/>	
Option 4: <input style="width: 95%;" type="text"/>	



## Beacon Threshold




Figure 23 - The BEACON THRESHOLD Menu

Path	HOME - FUNCTION - MENU KEY 6 (x8) - ENTER
or	From Models or System Setup CONFIG - MENU KEY 6 (x8) - ENTER
Description	On this screen the beacon signal strength at which the beacon level alarm trips is set.  Edit the value in the “Set Level” box using the numeric keypad. The ← & → move the cursor.
Note	The only function of the beacon level alarm is to operate a relay for external use. It is not used by the INTRAC algorithm and, when it occurs in isolation without an alarm from the IBR-L, has no effect on the INTRAC operation or mode.

Contrast & Brightness





Figure 24 - The CONTRAST & BRIGHTNESS Menu

Path	HOME - FUNCTION - SYSTEM SETUP - ENTER
	or From Models or Configuration - SYSTEM SETUP - ENTER
Description	<p>The screen Contrast and Brightness can be adjusted in this menu. The Contrast range is from 0 to 15 and the Brightness range is from 0 to 8.</p> <p>The levels are set using Menu Key 3 for contrast and Menu Key 4 for brightness. Each press of a key increases the displayed number by one and the screen brightness or contrast changes.</p> <p>When the display is at its most visible press ENTER to store the values.</p> <p>Menu Key 5 (Normal) sets the Brightness and Contrast to the default values which are 8 in both cases.</p>
Note	The Flicker setting is not an operator controllable parameter.
Warning	<p>When adjusting the brightness and/or contrast it is possible to blank the display! If this happens <b>do not panic</b>, continuing to press the same key will return the display to visible. Alternatively Menu Key 5 can be pressed which sets the default brightness and contrast levels.</p> <p>If a wrong key is pressed so that the INTRAC is no longer in the brightness and contrast setting facility, continuing to press keys could cause the loss of the orbit model.</p> <p>If the brightness &amp; contrast setting are in a state where the INTRAC display can not be read, carry out the following procedure. Press the emergency stop button, switch the INTRAC off, release the emergency stop button, switch the INTRAC on. Press the following keys, allowing time between each pressing, press Menu Key 1, press Menu Key 4, press Menu Key 5, press Enter, press Menu Key 5, the display should now be visible. Check that no parameters have been affected by key presses when the display was blank.</p>

*Fine Tune - Sense***Figure 25 - The FINE TUNE - SENSE Menu****Path**

HOME - FUNCTION - SYSTEM SETUP -  
MENU KEY 6 (x2) - ENTER

or

From Models or Configuration  
SYSTEM SETUP - MENU KEY 6 (x2) - ENTER

**Description**

This menu allows the “sense” of the Azimuth, Elevation and Polarisation resolvers to be inverted. This is necessary to allow for different mounting arrangements for the resolvers.

Use Menu Key 6 to step the edit highlight through the three angles. Use Menu Key 4 (Change Resolver Sense) to toggle between “true” and “inv.”

Pressing ENTER accepts the settings and moves on to the “FINE TUNE - Offsets” menu. (see next page)

Fine Tune - Offsets




Figure 26 - The FINE TUNE - OFFSETS Menu

Path	See “FINE TUNE - Sense” on previous page.
Description	<p>This menu allows an offset to be inserted between the “angle” from the resolver and the displayed angle in order to calibrate the system for any difference between the actual antenna angle and the resolver angle.</p> <p>The actual pointing angles of the antenna are accurately established and the displayed angles are set to those angles using this facility.</p> <p>Azimuth &amp; Elevation or Polarisation are selected using menu key 5.</p> <p>The setting of the offset is done using the manual drive keys. For Az &amp; El the right and left keys offset the Az and the upper and lower keys offset the El. For Pol the right and left keys are used.</p> <p>The angles displayed in the upper section of the menu screen change in real time. Menu Key 6 may be used together with the direction key to increase the rate of change.</p> <p>The actual amount of offset is not displayed.</p> <p>The offset can be returned to zero for any angle by pressing the opposite keys at the same time. Care should be taken to release both keys at the same time otherwise another offset will be inserted.</p>
Note	This should only be carried out at commissioning or on the installation of a new resolver or if the relationship between the antenna and a resolver has changed.
Caution	Inserting any offset will reset the orbit model.

## Station Co-ordinates

Function	
Current Mode	Tracking
Control State	Local
Beac Freq	11.452000 GHz
Level	-10.057°
El Angle	25.97°
Az Angle	210.50°
Pol Angle	27.4°

STATION COORDINATES	
Lat	: <input type="text" value="-123.1234"/> °+North
Long	: <input type="text" value="123.1234"/> ° East
Height	: <input type="text" value="+10.0000"/> km
Offsets-	
Az	: <input type="text" value="-180.1234"/> °
El	: <input type="text" value="-180.1234"/> °
Press EN to accept selection	

Standby	1	puts the antenna control system into STANDBY mode and skips to the HOME menu
Home	2	skips to the Home (root) menu
Models	3	skips to the Models menu
Config	4	skips to the Config menu
System Setup	5	skips to the System Setup menu
Next Field	6	moves the highlight box to the next field in the current menu

Figure 27 - The STATION CO-ORDINATES Menu

Path	HOME - FUNCTION - SYSTEM SETUP - MENU KEY 6 (x2) - ENTER
or	From Models or Configuration SYSTEM SETUP - MENU KEY 6 (x2)
Description	<p>The co-ordinates of the earth station are entered in this menu. Also any offsets required if the antenna base is not perpendicular.</p> <p>The five edit fields are stepped through using Menu Key 6 (Next Field). The values are entered using the Numeric Keypad.</p> <p>Pressing ENTER accepts the values.</p>
Note	These parameters are not required by the INTRAC-605 for its orbit modelling. However they are required if IESS-412 or NORAD Ephemeris data is to be used and for Star Track Mode.

Date & Time




Figure 28 - The DATE & TIME Menu

Path HOME - FUNCTION - SYSTEM SETUP -  
MENU KEY 6 (x3) - ENTER

or From Models or Configuration  
SYSTEM SETUP - MENU KEY 6 (x3) - ENTER

Description The date and time are entered in this menu.  
The edit box is stepped through the six fields using Menu Key 6 (Next Field). The values are entered using the Numeric Keypad. The clock uses the 24hr system.

Pressing ENTER accepts the values displayed.

- Note 1 The clock is battery backed.
- Note 2 The clock frequency can be adjusted by up to +/- 180 seconds per day in the “Time Rate Correction” menu which is accessed by Menu Key 3. (see next page)

## Time Rate Correction

Current Mode	Tracking	Function		
Control State	Local	Standby	1	puts the antenna control system into STANDBY mode and skips to the HOME menu
Beac Freq	11.452000 GHz	Home	2	skips to the Home (root) menu
Beac Level	-10.05 dB	Models	3	skips to the Models menu
El Angle	25.97°	Config	4	skips to the Config menu
Az Angle	210.50°	System Setup	5	skips to the System Setup menu
Pol Angle	27.4°		6	(not used)

TIME RATE CORRECTION	
Seconds/Day:	<input type="text" value="045"/>
Press EN to accept selection	

Figure 29 - The TIME RATE CORRECTION Menu

Path	HOME - FUNCTION - SYSTEM SETUP - MENU KEY 6 (x3) - ENTER - MENU KEY 3
Description	<p>Allows the time keeping accuracy of the clock to be adjusted.</p> <p>The adjustment is in the range from minus 180 seconds per day to plus 180 seconds per day,</p> <p>Use the Numeric Keypad to enter the value. The +/- key is used to set gain or loss.</p> <p>Pressing ENTER accepts the displayed value.</p>
Note	Changing the Time Rate Correction value does not affect the orbit model.

AZ & EL Beamwidth




Figure 30 - The AZ & EL BEAMWIDTH Menu

- Path
- HOME - FUNCTION - SYSTEM SETUP -  
MENU KEY 6 (x4) - ENTER
- or
- From Models or Configuration  
SYSTEM SETUP - MENU KEY 6 (x4) - ENTER

Description

This menu enables the setting of the antenna's Azimuth and Elevation 3dB beamwidths at the beacon frequency. These values are used by the INTRAC-605 to calculate the cross scan movement.

The edit box is stepped between Azimuth and Elevation with Menu Key 6 (Next Field). The beamwidth values are entered from the Numeric Keypad.

Pressing the ENTER key accepts the displayed values.



## Stow Setup

Function		
Current Mode	Tracking	Standby
Control State	Local	Home
Beac Freq	11.452000 GHz	Select Stow Use
Level	-10.05 dB	Stow/Unstow
El Angle	25.97°	
Az Angle	210.50°	
Pol Angle	27.4°	Next Field

1	puts the antenna control system into STANDBY mode and skips to the HOME menu
2	skips to the Home (root) menu
3	moves to the Select Stow Use menu
4	Stows (or Unstows) the antenna
5	(not used)
6	moves the highlight box to the next field in the current menu

**STOW SETUP**

Final Stow Positions:

Az angle

El angle

Preliminary Stow Positions:

Az angle

El angle

Press EN to accept settings

## Path

HOME - FUNCTION - SYSTEM SETUP -  
MENU KEY 6 (x5) - ENTER

or From Models or Configuration  
SYSTEM SETUP - MENU KEY 6 (x5) - ENTER

## Description

This menu is used to set the co-ordinates for the preliminary and final antenna stow positions.

With the antenna not in the Stow position pressing the Stow/Unstow key causes the antenna to be driven to the Final Stow Position via the Preliminary Stow Position.

**Note** The Preliminary and/or Final positions may be set to “used” or “not used” in the “Select Stow Use” menu (Menu Key 3). (see next page)

Menu key 6 (Next Field) steps the edit box through the four angle fields. The co-ordinates can be changed using the Numeric Keypad.

**Notes** If all positions are enabled the antenna is driven, in both axes, to the Preliminary Stow Position. When both axes reach that position the antenna is driven to the Final Stow Position and, where appropriate, the Stow Pins are driven in.

Unstow removes the Stow Pins (if appropriate) and drives the antenna to the Preliminary Stow Position.

The only antenna command possible from the Stow Position is Unstow.

Select Stow Use




Figure 31 - The SELECT STOW USE Menu

Path	MENU KEY 3 from “Stow Setup” on previous page.
Description	Allows the Azimuth and Elevation Preliminary & Final Stow Positions to be enabled or disabled.
Note	<p>If both Preliminary Stow axes are disabled the antenna will drive direct to the Final Stow position on pressing the Stow key. If only one Preliminary axes is disabled the antenna will drive in the other axis to its Preliminary position before carrying on to the Final position.</p> <p>Menu key 6 (Next Field) steps the edit highlight through the four fields. Menu Key 5 (Used/Not Used) toggles the selected field between used and not used. Pressing ENTER accepts the displayed settings and returns to the “STOW SETUP” menu.</p>

*Fitted Options*

Current Mode		Tracking	Function
Control State	Local	2000 GHz	Standby
Beac Freq	-11.45		Home
Beac Level	25.97%		
El Angle	210.50°		
Az Angle	27.4°		
Pol Angle			

Fitted Options		Function
Beacon Receiver:	Fitted	1 puts the antenna control system into STANDBY mode and skips to the HOME menu
Beac pol select:	Fitted	2 skips to the Home (root) menu
Polarization :	Fitted	3 (not used)
Mount Az/El :	Fitted	4 toggles the highlighted parameter between Fitted/Not Fitted
Type HrAng/Dcl :	Not Fitted	5 resets the menu to display the currently stored values
Resolver EG-01 :	Not Fitted	6 moves the highlight box to the next field in the current menu
Type RE-01 :	Not Fitted	
HD-001 :	Fitted	
Extended Az :	Not Fitted	
Geared Pol :	Not Fitted	
SimAx Drive :	Fitted	
Inv Beacon Lock:	Not Fitted	
Press EN to accept all fields		

**Figure 32 - The FITTED OPTIONS Menu****Path**

HOME - FUNCTION - SYSTEM SETUP -  
MENU KEY 6 (x6) - ENTER

or

From Models or Configuration  
SYSTEM SETUP - MENU KEY 6 (x6) - ENTER

**Description**

Various options such as polarisation drive and simultaneous axis drive are available on the INTRAC-605. Their use has to be programmed into the INTRAC in order for them to be usable. That programming is carried out in this menu.

The various options are shown on this screen.

Menu Key 6 (Next Field) steps the highlighted edit line through the options.

Menu Key 4 (Fitted/Not) toggles the option between fitted and not fitted.

Menu Key 5 (Recall Existing Settings) resets the options to the state they were in when this menu was entered.

Pressing ENTER accepts the displayed settings.

Geared POL




Figure 33 - The GEARED POL Menu

Path HOME - FUNCTION - SYSTEM SETUP -  
MENU KEY 6 (x7) - ENTER

or From Models or Configuration  
SYSTEM SETUP - MENU KEY 6 (x7)

Description The polarisation resolver may be geared to the antenna polarisation mechanism in such a way that there is not a 1:1 relationship between the resolver rotation and the polarisation rotation. If this is the case a special version of software is required to include the gearing ratio which must be specified at time of order.


Typically the resolver rotates faster than the polarisation angle and there is initially an ambiguity as the INTRAC does not know which segment the polarisation angle is in. The offset value (integer) is used to define the segment so that the displayed polarisation angle is correct.

After the initial segment definition, provided that the polarisation is not adjusted with the INTRAC switched off, the INTRAC will track the angle throughout the entire polarisation range.

Note It is set-up during commissioning and/or replacements only.

The offset value (between -3 and +2) is entered from the numeric keypad. Pressing ENTER accepts the displayed value.

Note This menu is only available if “Geared Pol” is set as fitted in the “Fitted Options” menu. (see previous page)

**Rapid Model Generate****Figure 34 - The RAPID MODEL GENERATE Menu****Path**

HOME - FUNCTION - MODELS - ENTER

or

From Configuration or System Setup  
MODELS - ENTER**Description**

IESS-412 & NORAD ephemeris data can be loaded into the INTRAC-605. This data is primarily for Program Track use. HOWEVER the INTRAC-605 can use this data to generate an ORBIT MODEL for the satellite. The advantage of this is that the model is available immediately rather than after the 24hrs it would take if the INTRAC had to learn the orbit. The INTRAC is then immediately immune to long beacon outage or power failures.

The INTRAC will accept the ephemeris data two days either side of the data's actual validity period.

The SGP/SDP modelling algorithms for the NORAD data will give slightly different pointing results for a given set of data. Except that the SGP4/8 algorithms are for Near Earth orbits and SDP4/8 are for Deep Space orbits. (Geostationary Orbits are SDP). The INTRAC will not allow a model to be made using the wrong type of orbit algorithm.

It is assumed that the user will know which NORAD algorithm applies for the data being used.

Menu Key 6 (Next Field) steps the selecting highlight through the seven selections. Once the required selection is highlighted pressing ENTER causes the model to be generated and the INTRAC to enter Tracking Mode.

**Note**

For more information on working with IESS-412 & NORAD data see page 76.

Program Track




Figure 35 - The PROGRAM TRACK Menu


Path HOME - FUNCTION - MODELS - MENU KEY 6 - ENTER

or From Configuration or System Setup  
MODELS - MENU KEY 6 - ENTER

Description IESS-412 or NORAD ephemeris data can be used, if required, to operate the INTRAC-605 in Program Track mode.

Note Much better tracking is achieved by the INTRAC either building an orbit model from its learning mode or by generating an orbit model from IESS-412 or NORAD data.

Menu Key 6 (Next Field) steps the highlighted selection bar through the seven algorithm selections. Pressing ENTER accepts the highlighted selection and initiates IESS Track mode, i.e., Program Tracking.

*Reserve Model***Figure 36 - The RESERVE MODEL Menu**

Path	HOME - FUNCTION - MODELS - MENU KEY 6 (x2) - ENTER
or	From Configuration or System Setup MODELS - MENU KEY 6 (x2) - ENTER
Description	<p>Once the INTRAC-605 has built an orbit model it can track the satellite with no tracking signal for 72hrs. After this time if there is still no signal the INTRAC deems the model to be expired and ceases to track.</p> <p>In such a situation the INTRAC can fall back into Program Track mode using the “Reserve Model”.</p> <p>The “Reserve Model” requires that valid IESS-412 or NORAD data be loaded and that the required reserve model is selected.</p> <p>In this menu the required reserve model, IESS-412 or NORAD is set.</p> <p>Menu Key 6 (Next Field) steps through the two selections. Pressing ENTER accepts the highlighted selection.</p>
Note	The words SET and NOT SET following IESS-412 and NORAD refer to the previous selection. Pressing ENTER will make the highlighted selection SET and the other NOT SET regardless of the current displayed state.

Edit IESS-412




Figure 37 - The EDIT IESS-412 Menu

Path HOME - FUNCTION - MODELS - MENU KEY 6 (x3) - ENTER

or From Configuration or System Setup MODELS - MENU KEY 6 (x3) - ENTER

Description This menu is used to input IESS-412 data. It comprises three screens the first of which is shown above. The full IESS-412 data is entered into the three screens. Pressing enter after all the data has been entered causes a check to be made on the data for validity. If the check is OK the data is accepted.

For more information on working with IESS-412 data see page 76.

Menu Key 6 (Next Field) steps the edit box through the edit fields. The data is input using the numeric keypad. Pressing ENTER steps onto the next page.

Menu Key 4 returns to the first page from page two or page three. Pressing ENTER on page three causes the data to be checked and accepted if valid.

Note In the IESS-412 data supplied the LMO value is in the range - 180° to +180°. The INTRAC-605 cannot accept negative values for this field from the front panel. (It can from the RCM-4) It is therefore necessary to add 180° to the supplied value when entering from the front panel. This only applies to the LMO data field.



*Edit NORAD Buffer*

			Function
Current Mode	Tracking		Standby
Control State	Local		Home
Beac Freq	-11.452000 GHz		Valid check
Level	-10.057°		A - Z
Angle	25.97°		Decimal Point
Az Angle	210.50°		Next Field
Pol Angle	27.4°		
<u>Edit NORAD BUFFER</u>			
Char No:019			
92 50 A 95100.94672			
Min Intv 3			
Day Perd 28			
Press EN to accept all fields			

1	puts the antenna control system into STANDBY mode and skips to the HOME menu
2	skips to the Home (root) menu
3	checks the validity of the contents of the NORAD buffer
4	cycles the character at the cursor position through the alphabet
5	inserts a decimal point at the cursor position
6	moves the highlight box to the next field in the current menu

**Figure 38 - The EDIT NORAD BUFFER Menu**

Path	HOME - FUNCTION - MODELS - MENU KEY 6 (x4) - ENTER
or	From Configuration or System Setup MODELS - MENU KEY 6 (x4) - ENTER
Description	<p>This menu is used to input NORAD Ephemeris data.</p> <p>Menu Key 6 (Next Field) steps the edit box through the three entry fields. The NORAD string data is entered in the top box. Char No: ____ indicates the position of the cursor in the data string. As the cursor reaches the right end of the edit box the data scrolls.</p> <p>Data is entered/edited using Menu Keys 4 &amp; 5 (A - Z and Decimal Point) and the Numeric Keypad.</p> <p>To enter an alphabet character position the cursor and press Menu Key 4. Each press steps the character at the cursor position through the alphabet.</p> <p>Menu Key 5 inserts a decimal point at the cursor position.</p> <p>The +/- key on the Numeric Keypad inserts a - or a space at the cursor position. One press inserts a - and the next a space.</p> <p><b>Note</b> Inserting a number causes the cursor to step to the next character position. However inserting a letter, a - or a space does not and the → key must be used to move on.</p> <p>Min Intv = Minimum Interval Day Perd = Day Period</p>

Edit Star Track




Figure 39 - The EDIT STAR TRACK Menu

Path	HOME - FUNCTION - MODELS - MENU KEY 6 (x5) - ENTER  or From Configure or System Setup MODELS - MENU KEY 6 (x5) - ENTER
Description	<p>The Star Track Model keeps the antenna pointed at a specific star by compensating for the rotation of the earth.</p> <p>It requires the co-ordinates of the star to be input together with the date and time of those co-ordinates. The model is then built using above data and the Station Co-ordinates. (see Station Co-ordinates menu on page 43)</p> <p>Menu Key 6 (Next Field) steps the edit box through the eight data fields. The data is entered using the Numeric Keypad. Pressing ENTER accepts the displayed data and enters Star Track mode.</p>
Note	This facility is used for engineering purposes.

**Edit Satellite Table**

			Function
Current Mode	Tracking		Standby
Control State	Local		Home
Beac Freq	11.452000 GHz		Models
Level	-10.05 dB		Config
El Angle	25.97°		System Setup
Az Angle	210.50°		Next Field
Pol Angle	27.4°		
<b>Edit SATELLITE TABLE</b>			
Satellite Number	01		
Elevation	33.74°		
Azimuth	162.83°		
Polarization	- 90.0°		
Band	1		
Frequency	950.000000 MHz		
Press EN to accept selection			

1	puts the antenna control system into STANDBY mode and skips to the HOME menu
2	skips to the Home (root) menu
3	skips to the Models menu
4	skips to the Config menu
5	skips to the System Setup menu
6	moves the highlight box to the next field in the current menu

**Figure 40 - The EDIT SATELLITE TABLE Menu**

Path

HOME - FUNCTION - MODELS -  
MENU KEY 6 (x6) - ENTER

or

From Configuration or System Setup  
MODELS - MENU KEY 6 (x6) - ENTER

Description

This is the same menu as "Edit Satellite Table" under the Configuration Menu. (see page 29)

Clear Models




Figure 41 - The CLEAR MODELS Menu

Path	HOME - FUNCTION - MODELS - MENU KEY 6 (x7) - ENTER
	or From Configuration or System Setup MODELS - MENU KEY 6 (x7) - ENTER
Description	<p>With this menu the actual INTRAC orbit model is cleared or the IESS-412 data and/or the NORAD data is flagged as being no longer valid.</p> <p>If, after clearing the INTRAC model, Auto Continue is pressed the INTRAC enters Learning Mode.</p> <p>If, after clearing the IESS-412 Model, IESS412 is selected for “Rapid Model Generate” or for “Program Track” the INTRAC enters the “Edit IESS-412” menu for the data to be updated.</p> <p>Similarly if NORAD is selected for “Rapid Model Generate” or “Program Track” after the NORAD Model has been cleared the INTRAC enters the “Edit NORAD” menu for the data to be updated.</p>

## Show Alarms




Figure 42 - The SHOW ALARMS Menu

## Path

HOME - SHOW ALARMS (Menu Key 5)

## Description

This screen shows all the currently active alarms, both primary and secondary. If there are more alarms active than can be displayed on one page "MORE" is appears at the bottom of the screen. Menu Keys 5 & 6 can then be used to move through the pages of alarms. If there is only one page of alarms Menu Keys 5 & 6 are not labelled.

Primary alarms will cause the System Alarm indicator to illuminate drawing attention to the fact that an alarm has become active. Secondary alarms do no illuminate the indicator but will still be displayed on the alarms screen even if there are no primary alarms.

## Note

The alarm conditions do not update automatically whilst being displayed. To check if an alarm state has changed press Menu Key 4 (Clear Alarms) to clear the display. Follow this by pressing Menu Key 3 (Update Alarms) to display the current alarm state.

Remote/Local




Figure 43 - The REMOTE/LOCAL Menu

Path HOME - MENU KEY 6

Menu Key 6 toggles the INTRAC-605 between Local (Front Panel) and Remote control/operation.

Compare the above screen (remote selected) with the one for the Home menu (local selected).

With Remote selected only three functions are available on the front panel. The ability to display the active alarms (Show Alarms), the ability to select Standby and the ability to return control to Local. All other menu functions are transferred to the Remote Terminal.

Note Because the Diagnostics On/Off selection in the Configuration Menu affect the Remote Port (see page 36) in order to be able to use the Remote Terminal facility Diagnostics MUST be set to OFF.

## Normal Operation

### *Continuing Tracking*

With the INTRAC-605 operating normally it will be in Tracking Mode and will require no operator input.

Should it become necessary to move the antenna off satellite for a period less than 72 hours, such as to stow it because of wind, all that is required to resume tracking is to select Auto Continue. (after the antenna has been unstowed)

### *To Track a new Satellite*

Set the Beacon Frequency.

Set the Polarisation angle if motorised Pol fitted.

Point the antenna at the required satellite using Manual control, Goto Position or Goto Satellite.

Peak the antenna on the beacon signal using Manual control or Search.

When the antenna is peaked on the beacon signal cause the INTRAC to enter Learning Mode by selecting Auto New Model.

After 24 hours of learning the INTRAC will automatically enter Tracking Mode.

#### Note

If Auto Continue is selected instead of Auto New Model and the previous model has not been cleared the antenna will drive back to the previous satellite and continue tracking it.

If the beacon signal is lost the INTRAC will enter Predicting Mode. It will then track the satellite by predicting from the model for a period of time depending on how long it has been learning. If Tracking Mode had been achieved before the signal is lost the INTRAC will track in Predicting Mode for up to 72 hours after which time it will deem the model to no longer be accurate enough.

When the beacon signal returns, if the INTRAC is still in Predicting Mode, Tracking Mode will be resumed. If the INTRAC has entered Standby, due to the period without signal being too long, Learning Mode will have to be invoked from the front panel.

Manual Velocity Operation

Note In auto modes variable speed CSO is transparent to the user. The INTRAC generates drive signals appropriate for the move required.

In Manual (P) mode two options are available -

- a) standard two speed manual drive, slow by using the Manual Control keys alone or fast by using them in conjunction with the Latch Drive key.
- b) variable speed drive by selecting the Velocity screen from the Manual screen and using the Manual Control keys to ramp the drive speed.

velocity screen To select the velocity screen press menu key 3 (Velocity) from the Manual mode screen (see below).

Manual

Current Mode Local

Manual (P) Mode

Beac Level -10.05 B

Beac Freq 11.452000 GHz

El Angle 25.72°

Az Angle 210.501°

Press manual controls to command motion

Manual

Standby

Home (New Mode)

Velocity

Stow/Unstow

Select Az/El (Pol)

Latch Drive

1

puts the antenna control system into STANDBY mode and skips to the HOME menu

2

skips to the Home (root) menu from where the New Mode menu is selectable

3

moves to the Manual Velocity screen

4

Stows or Unstows (toggle) the antenna depending on its current state

5

(toggle) selects whether manual control buttons drive Az/El or Pol axes

6

latches the currently operated manual Drive button until pressed a second time

The Manual Velocity screen is then displayed -

Function

Current Mode Manl Velocity

Control State Local

Beac Freq 11.452000 GHz

Beac Level -10.05 dB

El Angle 25.72°

Az Angle 210.50°

MANUAL VELOCITY

El Angle 23.906 deg

El velocity: +0.127 deg/sec

Az Angle 187.206 deg

Az Velocity -0.073 deg/sec

Press Man Cntrl to Ramp Speed

Press both directions to stop

Function

Standby

Home

New Mode

1

puts the antenna control system into STANDBY mode and skips to the HOME menu

2

skips to the Home (root) menu

3

skips to the New Mode menu

4

not used

5

not used

6

not used

Pressing a Manual Control key causes drive in the appropriate direction to in to slow until zero speed is reached when drive will commence in the opposite direction. To stop drive press both keys together, i.e., Az right & left or El up & down. Take care to release them both together or drive will re-start in the direction of the key last released! The drive speed in degrees per second is displayed for both axes, the + & - symbols indicate direction, e.g., + deg/sec for Az Velocity indicates an increasing Az angle.


After the antenna has been driven in Manual Velocity mode the Home screen displayed mode is "Position Hold". This



indicates that the antenna is being held stationary by the counter torqued motors rather than by the brakes.

### *Position Hold*

Position Hold mode is entered after a Manual Velocity move, after a Goto move or after a Search instigated from the front panel. A non CSO system would enter Standby at these times.



### *Standby*

Standby mode causes the antenna brakes to be applied and power to be removed from the motors. Standby is either selected manually by Menu key 1 or selected automatically by a Primary Alarm being raised.

Deliberately left blank

## 5. ALARMS & ERRORS

The INTRAC-605 has two type of alarm condition. Primary Alarms and Secondary Alarms. The system will go into Standby mode if a Primary Alarm is triggered. Secondary Alarms leave the INTRAC in its current mode.

### Primary Alarms

A Primary Alarm becomes active if one (or more) of the following conditions arise:-

- Antenna movement limit switch activated.
- Software limit tripped.
- Emergency Stop button operated.
- Interlock switch activated.
- Motor drive failure. (Drive Fail Alarm)
- Antenna moves in wrong direction. (Drive Fail Alarm)
- Hardware (processor) fault.
- Antenna driven within  $1.4^{\circ}$  of  $0^{\circ}$  Az in the Northern Hemisphere or within  $1.4^{\circ}$  of  $180^{\circ}$  Az in Southern Hemisphere (Drive Fail Alarm).
- Resolver fault. (Synchro alarm) (apparent position change of more than  $1.4^{\circ}$  in  $1/64$  second).

### *Drive Fail Alarm*

The Drive Fail Alarm encompasses a number of other alarms. If there has been no change in the least significant bit (LSB) of the resolver output within 10 seconds of drive being activated. If either Az or El axis drive more than  $1.4^{\circ}$  in the wrong direction. If the antenna is driven within  $1.4^{\circ}$  of North (Azimuth  $0^{\circ}$ ) {or  $1.4^{\circ}$  of South (Az  $180^{\circ}$ ) Southern Hemisphere}.

The Drive Fail Alarm is not activated in Manual (P) Mode.

If a drive time-out occurs the INTRAC enters Standby Mode. This prevents the drive motors being damaged by continually re-starting.

When any Primary Alarm becomes active the red "System Alarm" indicator on the INTRAC front panel illuminates and the system enters Standby Mode. The actual alarm which has occurred can then be viewed on the screen by pressing Menu Key 5 (Show Alarms) in the Home menu.

**Secondary Alarms**

There are three Secondary Alarms :-

- Unable to Predict Alarm.
- Beacon Alarm.
- Servo Alarm.

*Unable to Predict*

This alarm is raised when the INTRAC has not enough confidence in the orbit model to be able to predict the satellites position. e.g. during the early part of learning a new model or after there had been no beacon signal for more than 72 hours.

*Beacon Alarm*

The Beacon Alarm is raised when the signal strength does not vary during step cycles or when beacon lock is lost.

*Servo Alarm*

The Servo Alarm is raised when the INTRAC fails to detect the expected amount of antenna movement during a step cycle. This can be caused by the servo performance not corresponding to the routine's model of the antenna drive characteristics. The INTRAC reacts by repeating the step cycle with a larger drive demand.

Secondary Alarms do not, necessarily, mean that there is a system fault nor do they illuminate the System Alarm indicator. The occurrence of a secondary alarm may be checked by selecting Show Alarms in the Home menu.

**Alarm Outputs**

Three sets of changeover relay contact outputs are available on a 25-way D-type connector on the INTRAC rear panel. There is one relay for a Primary Alarm, one for a Secondary Alarm and the third indicates that the beacon signal has fallen below the user set beacon threshold.

**Recovering from Alarms**

All Primary Alarms, except the Hardware Alarm in Auto Mode, cause the unit to be put into Standby Mode. Recovery from Drive Fail, Synchro and Hardware (other than when in Auto Mode) Alarm conditions are cleared by pressing any Mode selection key. Soft Limit and hard limit alarms can only be cleared by driving back from the limit using Manual Mode. Emergency Stop and Interlock alarms can only be cleared by removing the cause of the alarm.

If a Hardware Alarm occurs when the INTRAC is in Auto Mode the unit will perform a processor reset and then enter learning mode to re-learn the orbit model.

**Power Failure**

The INTRAC incorporates non-volatile memory and a battery backed real time clock. The onset of a power failure is detected and the current mode is stored before the processor ceases to operate. When power is restored the INTRAC performs an automatic recovery as below :-

If the unit was in Auto (Tracking) Mode at the time of the power failure and no Primary Alarms have become active the unit will resume tracking. The antenna will be moved (if necessary) to the current satellite position based on the orbit model and the real time clock.

If the unit was in Auto (Learning) Mode it will resume in that mode. However whether it continues learning or re-starts to learn depends on the ratio of the completed learning time to the period without power. (i.e. how dependable the learnt orbit will now be)

If the INTRAC was in any other Mode or if a Primary Alarm had occurred the unit will power up in Standby Mode with a power-up alarm.

**Errors**

Errors are user errors and involve the entry of non valid data.

Where data is entered outside the allowable limits for that data such as setting the beacon frequency outside the range of the selected band. The entered data is changed to the limit nearest to the entered value and marked with an asterisk (\*). On the bottom of the screen the message :-

“ENTRY ERROR!, limits forced =\*”

is displayed.

The forced limit data may be accepted by re-pressing the ENTER key or the correct value keyed in.

**IESS-412 Data**

Where IESS-412 data is entered with the incorrect 170hr checksum the checksum is corrected by INTRAC in the same manner as above. However it is up to the user to ascertain that it was the checksum which was wrong and not that wrong value data was entered.

Deliberately left blank

## 6. TECHNICAL DESCRIPTION

This section looks at and explains the Operational Modes and Functions of the INTRAC-605 and at the tracking algorithm that makes the INTRAC-605 one of the most accurate tracking antenna controllers available.

The INTRAC-605 achieves its very high accuracy satellite tracking by building a model of the satellite's orbit and then by using that orbit model to direct the antenna.

The algorithm used to build the orbital model has been continually developed and enhanced by Signal Processors Limited (SPL)/Advantech AMT Limited since 1983.

The tracking accuracy is typically similar to that achieved by a monopulse system and can, under some conditions, be better than that achieved by a monopulse system.

### The Tracking Algorithm

During initial acquisition the INTRAC algorithm tracks the satellite using a third order (for each axis) unbiased tracking filter. This algorithm dynamically adjusts the period between the step cycles to match the perceived orbit inclination and received beacon signal level fluctuations and noise level. During this initial period the tracking accuracy is only very slightly lower than the full long term INTRAC tracking accuracy.

The most significant difference during the learning period (first 24hrs) is not the accuracy of tracking but the time for which the system can predict in the event of loss of the beacon signal. This can be overcome by using Intelsat IESS-412 or NORAD data to establish an initial INTRAC model so that the full prediction ability is available from the start. This model is then modified and optimised by the INTRAC algorithm in the same manner as it would continuously update a model it had "learnt".

The key to deriving a reliable and accurate orbital model is the ability to derive accurate estimates of the many parameters involved in the model. Much specialised noise processing expertise and experience has been applied in the design of the INTRAC algorithm to ensure that INTRAC can build an accurate model and can maintain it even when the beacon signal is subject to severe fluctuations.

The INTRAC algorithm uses a robust pointing error estimator to obtain the raw satellite position estimate, normally at 10 minute intervals. The raw satellite position estimate is filtered with a narrow noise-bandwidth tracking filter to produce the basic, multi parameter, orbital model. To correct short-term errors in the basic model resulting from modelling error, windage and satellite station keeping manoeuvres, the difference between the raw satellite position estimate and the orbital model is filtered with another tracking filter (known as the "relationship algorithm")

capable of tracking and correcting transients. This is then combined with the basic model to form a reliable predictor that tracks mean windage, refraction and stationkeeping manoeuvres without error.

The INTRAC tracking filters are designed in such a way as to enable the model to provide the required accurate pointing prediction at all times. Even when not verified by measurements, as for example occurs with loss of beacon, the tracking filters are capable of accurately predicting the satellite orbit for many days. Under INTRAC control, pointing is always controlled from the internal satellite orbit model. When a measurement cycle is performed, it is always done as a perturbation with respect to current pointing. Thus, unlike conventional steptrack, INTRAC is always on track when a measurement cycle is performed. INTRAC never uses the measurement cycle for the purpose of directly bringing the beam on track. INTRAC simply performs one measurement cycle in each axis every 10 minutes in order to up-date the parameters used in the orbital model and for the rest of the time keeps the beam correctly pointed.

As a result of the combination of thermal noise, fade, scintillation, random windage-induced platform-reference motion, and other noise sources, the beacon signal will, during a measurement cycle, contain noise additional to that directly attributable to the measurement cycle itself. Careful algorithm design ensures that this noise has zero mean value and has a value of standard deviation such that it is equivalent to thermal noise of a certain effective value of C/No. By special design of the measurement cycle the INTRAC system minimises this effective value of C/No in a way that is not possible with conventional steptrack methods. Furthermore the INTRAC measurement cycle design discriminates so effectively against the slow component of received beacon signal power fluctuation, caused for example by rain fades, that it almost completely suppresses errors caused by linear beacon ramps of all practicable slopes.

The INTRAC algorithm also incorporates adaptive compensation for imperfections in the antenna drives. As a result its performance is largely unaffected by servo backlash, AC track motor drive rate and transportation rate (motor to axis rate) and coast, because of the specific choice of perturbation pattern and the use of high resolution position transducers. The INTRAC servo algorithm dynamically calibrates the mechanical coast of the antenna and automatically compensates for it if it is within reasonable limits (less than 1/20 beamwidth).

Wind affects tracking in two ways. The antenna structure is distorted by the wind load and this distortion shifts the beam pointing relative to the angle transducer reading. This component of beam shift is not visible to the position transducers. The mean of the reference shift is tracked by the



INTRAC algorithm in a similar way to a stationkeeping manoeuvre.

The component of beam shift that is visible to the position transducers is entirely tracked by INTRAC within a 10 mHz noise bandwidth. When the position transducers accurately reflect beam deflection in wind INTRAC continuously tracks this antenna deflection at 16 sec updates. To support tracking of visible wind-induced beam deflection between measurement cycles the INTRAC servo control algorithm maintains a short-term average of beam pointing. When deciding whether to update beam pointing INTRAC references this average rather than the current pointing. A further small deadband is also applied to suppress unnecessary hunting.

The INTRAC tracking filter distinguishes received beacon signal power fluctuations, fades and noise from the mean component of windage-induced beam-pointing, orbit changes and beam refraction. The effect of the fluctuations, fades and noise on the INTRAC tracking filter is as if these were a zero mean position random noise source. The variance of these is brought within specification by tracking the position estimates with a narrow noise bandwidth tracking filter. The mean components of windage-induced beam-pointing, orbit changes and refraction are seen as transients to be tracked by the INTRAC relationship algorithm. The design of the relationship algorithm is a carefully evolved working compromise between transient performance and noise suppression which provides high accuracy tracking under all conditions likely to be encountered in practice.

**The Modes**

The INTRAC-605 has six major operational modes :-

- Standby
- Auto - (tracking but includes learning & predicting)
- Manual - (including manual velocity sub mode)
- Goto - (Goto Satellite, Goto Position & Search)
- Sleep - (alarm induced, not user selectable)
- Remote (transfers control to a remote terminal)

**Standby**

Standby mode is a “no movement” mode, the antenna is not driven (the brakes where fitted will be applied) but the pointing angles and beacon signal level are monitored and displayed. External inputs to the INTRAC are also monitored and any primary alarms which occur are indicated. Any primary or secondary alarms will be displayed if “Show Alarms” is selected.

Standby mode is entered in one of three ways :-

- selected by the operator
- a primary alarm occurs
- at the end of a Goto move or at the end of a search

**Auto (normal operating mode)**

After pointing and peaking the antenna at the required satellite Auto New Model should be selected. This will cause the INTRAC to enter its period of learning the satellite's orbit.

The INTRAC performs cross scans to determine the satellite's position. These scans are performed at intervals (normally ten minutes but more frequently if INTRAC deems necessary) and the pointing parameters used to build the orbital model. When carrying out a cross scan the antenna describes a small cross (normally +/- 5% of the antenna's 3dB beamwidth) in the sky to determine the satellite position estimate.

After 24hrs the INTRAC has built the full orbital model. However during the building process the INTRAC maintained a simple orbit model for the satellite which allowed INTRAC to track with very nearly the same accuracy as its long term accuracy.

Once the model is complete the INTRAC enters Tracking Mode. The model is used to point the antenna and because of the high

accuracy of the model the tracking is within 0.05dB of peak signal tracking.

In Tracking Mode the INTRAC continuously updates the model by making small perturbations of the antenna and incorporating the resultant data into the model. During periods when the satellite's orbit is changing because of station keeping manoeuvres the INTRAC may increase the frequency of the perturbations.

If the beacon receiver stops providing a useful signal\* the INTRAC will enter "Predicting" sub mode. In this mode the INTRAC will continue to point the antenna according to the model but will not update the model. Once "Tracking Mode" has been achieved "predicting" can continue for 72hrs. If the beacon receiver returns to providing a useful signal\* within this period the INTRAC returns to updating the model. If, after 72hrs, the beacon is still not producing a useful signal\* the model is deemed to have expired. If this occurs the INTRAC can fall back on the "Reserve Model" which is a Program Track using either IESS-412 or NORAD data. (see Reserve Model - page 53)

\* useful signal

A useful signal is defined as one that varies sensibly during antenna movements, is neither over or under range and the beacon receiver is in lock.

### *Manual*

Manual Mode allows the operator to drive the antenna using the Manual Control keys on the INTRAC front panel. It is normally only used for small movements of the antenna such as peaking when the position of the satellite is known with close accuracy. For larger antenna movements one of the Goto modes is faster and where the satellite's position is only roughly known search is employed to peak the antenna.

There are two main Manual Modes. Manual (P) Mode is manual control from the front panel. Manual (A) Mode is manual control from the Remote Terminal. (See section 10 - REMOTE CONTROL TERMINAL). The antenna can be driven through North (Azimuth 0°), in the Northern Hemisphere, or South (Az 180°), in the Southern Hemisphere, only in Manual (P) Mode.

Manual drive may be standard, i.e., two speed - fast or slow, or velocity, i.e., variable speed. See page 81 for a description of velocity drive.

<i>Goto</i>	There are three Goto sub modes. Goto Position and Goto Satellite provide a convenient method of driving the antenna to a specific position. Search mode is the automatic scanning of an area of sky for a satellite.
<i>Goto Position</i>	In this mode the operator enters the co-ordinates and beacon frequency of the required satellite and presses the enter key. The entered co-ordinates are checked for validity (i.e. are they within the soft limits?). If they are invalid the INTRAC sets the maximum possible angle(s) in the required direction and prompts the operator for action. If the co-ordinates are valid the INTRAC drives the antenna to those co-ordinates and enters Standby. The antenna can then be peaked using manual mode or search mode (see below) before selecting Auto New Model.
<i>Note</i>	If Auto Continue is selected at the end of Goto and there is a model in existence the INTRAC will continue to track using that model. To commence learning a new orbit either Auto New Model should be selected or any existing model cleared before selecting Auto Continue.
<i>Goto Satellite</i>	This mode allows one of the previously programmed satellites (up to 40 can be programmed) to be selected by number and its position driven to. Using the "Edit Satellite" sub menu of the Goto Satellite menu a new satellite can be added or an existing one edited. Having selected the required satellite pressing the enter key causes the antenna to be driven to that satellite. The INTRAC enters Standby when the antenna is at the satellite's position. Antenna position peaking can then be carried out manually or in search mode (see below). To commence tracking this new satellite select Auto New Model or if there is no existing model Auto Continue may be selected. (see Note above)
<i>Search</i>	<p>Search Mode conducts a search of the sky based on parameters entered in this menu. When the menu is entered the displayed parameters are those of the current antenna pointing. e.g. the parameters from a Goto move. If these parameters are not those required they may be edited in this menu (see page 25).</p> <p>The search box size angles are plus and minus on the nominal angle. Thus entering 2° by 2° would cause a search box of 4° square.</p> <p>The search begins in the nearest corner of the defined box to the antenna's current pointing. The search pattern is a "toast rack" or "serpent shape. The scanning comprises full scans in elevation for each move in azimuth. The azimuth move is equal to the 3dB beamwidth of the antenna commencing 1/2 of the 3dB beamwidth in from the edge of the box.</p> <p>The position of the highest beacon signal strength during these scans is recorded. At the end of the "serpentine" search the</p>

antenna is driven to the point of highest signal strength found during those scans and phase two of the search is commenced. This is the peaking phase and causes the antenna to search a smaller area of sky around the point of highest signal strength for the peak level. Again the position of the highest signal strength is recorded and at the end of this phase the antenna is driven to that position and the INTRAC enters Standby. At this point the peak may be confirmed manually and/or learning mode entered by selecting Auto New Model.

### *Sleep*

Sleep Mode is the mode the INTRAC enters when it cannot drive the antenna due to some disabling occurrence. INTRAC continues to monitor the occurrence and when it has cleared antenna drive control continues.

Sleep mode is entered under three conditions.

1. if the antenna is unable to be driven due to a power failure at the Motor Drive Cabinet (which does not affect the INTRAC itself).
2. if the Motor Drive Cabinet is switched into local control.
3. if an external emergency stop switch is operated.

Conditions 2 & 3 are detected by the INTRAC by the Interlock alarm becoming active.

Condition 1 is detected by all four direction limit switches becoming active. This occurs because relays are normally operated and drop out with no power.

The Primary alarm is activated and the INTRAC screen displays "SLEEP".

When the condition causing Sleep mode ceases the INTRAC will attempt to return to the mode it was in prior to Sleep mode. If this was Tracking the INTRAC will re-position the antenna according to the model and continue tracking.

**Note** If the INTRAC is in Remote Mode when Sleep is entered the remote will appear to be in Standby Mode with the Interlock alarm or all four limit switches active.

### *Remote*

Remote Mode transfers control of the INTRAC to a remote terminal.

It is selected with Menu Key 6 (Select Remote) from the Home menu. Once in Remote Mode only four functions are available

from the INTRAC front panel. The emergency stop switch will inhibit the antenna drive as normal, the alarms can be displayed, Standby Mode can be entered and control can be returned to the front panel again with Menu Key 6 (Select Local).

### Using IESS-412 or NORAD Data

The INTRAC-605 can make use of Intelsat IESS-412 11-parameter or NORAD ephemeris information in two ways.

1. The information can be used by the INTRAC to generate an INTRAC model of the satellites orbit. This model can then be used by the INTRAC as it would use a model it had learnt itself. This means that there is not the need for the 24hr learning period. The model is then updated as any INTRAC model would be.
2. The INTRAC can be commanded to Program Track using positions calculated from the ephemeris data set.

The IESS-412 and NORAD data sets can be entered either manually from the INTRAC front panel or from a PC. A stand alone program is available for loading the data file from a PC. This program can be used alone or in conjunction with the Remote Control Terminal RCM-4. A description of this program is given in an attached appendix (see Appendices Contents).

#### *The IESS-412 data*

The IESS-412 data set comprises 21 fields of data :-

IESS Epoch Year	range: 80 to 99 (this century) 00 to 79 (next century)
IESS Epoch Month	range: 1 to 12
IESS Epoch Day	range: 1 to 31
IESS Epoch Hour	range: 0 to 32
IESS Epoch Minute	range: 0 to 59
IESS Epoch Second	range: 0 to 59
IESS Minutes Interval	range: 0 to 59
IESS Days Validity	range: 0 to 28
IESS Sat LM0	range: 0 to 360 deg
IESS Sat LM1	range: -9.99 to 9.99 deg/day

IESS Sat LM2	range: -9.99 to 9.99 deg/deg/day
IESS Sat LONC	range: -9.99 to 9.99 deg
IESS Sat LONC1	range: -9.99 to 9.99 deg/day
IESS Sat LONS	range: -9.99 to 9.99 deg
IESS Sat LONS1	range: -9.99 to 9.99 deg/day
IESS Sat LATC	range: -9.99 to 9.99 deg
IESS Sat LATC1	range: -9.99 to 9.99 deg/day
IESS Sat LATS	range: -9.99 to 9.99 deg
IESS Sat LATS1	range: -9.99 to 9.99 deg/day
IESS Sat LONG170	range: 0 to 360 deg
IESS Sat LAT170	range -9.99 to 9.99 deg/day

Also required to be set are the IESS Az & El offsets which are input on the Function - System Setup - Station Coordinates menu screen.

The IESS Epoch defines the time instant at the start of the period of the IESS data. The IESS Minutes Interval defines the period in minutes between pointing updates in Program Track mode. The IESS Days Validity (normally 7) defines the period of validity of the data. The INTRAC will accept and use the data two days either side of the validity period.

The parameters IESS Sat (LM0, LM1, LM2, LONC, LONC1, LONS, LONS1, LATC, LATC1, LATS, LATS1) are the IESS-412 11-element ephemeris. The parameters IESS Sat (LONG170, LAT170) are the IESS-412 11-element ephemeris 170hr parity check.

- Note The data ranges shown above as +/- 9.99 actually accept more than two places of decimals.
- Note The LMO value is given in the range -180° to +180°. The INTRAC-605 cannot accept negative values for this field from the front panel. (It can accept them from the RCM-4). It is therefore necessary to add 360° to the supplied value if it is negative when entering from the front panel. This only applies to the LMO data field.

### NORAD Data

The NORAD ephemeris data consists of a string of 166 characters. The first 160 characters are split into two "Card Element Sets" of 80 characters each. The next two characters (161 & 162) comprise the Minutes Interval and characters 163 &

164 comprise the Period of Validity of the ephemeris. The final two characters (165 & 166) are the check sum.

There are ten blocks of orbital element parameters contained in the NORAD ephemeris character string :-

Charas.	Data	Description
19 - 32	EPOCH	format - YYDDD.DDDDDDDD
34 - 43	XNDT20	1st rate of change (rev/day/day)
45 - 52	XNDD60	2nd rate of change (rev/day/day/day)
54 - 61	BSTAR	damping factor ( $e^{*-1}$ )
89 - 96	XINCL	inclination (deg)
98 - 105	XNODEO	ascending node (deg)
107 - 113	EO	eccentricity
115 - 122	OMEGAO	argument of perigee (deg)
124 - 131	XMO	mean anomaly (deg)
133 - 143	XNO	mean motion (rev/day)

## Rapid Model Generation

The INTRAC-605 can use the IESS-412 or NORAD data to build the satellite's orbit model instead of having to learn the orbit over a 24hr period.

The IESS-412 data is simply selected for the Rapid Model Generation in the Models menu and ENTER pressed. The orbit model is calculated and the INTRAC enters Tracking Mode.

For the NORAD data there are five choices of NORAD algorithm. These are SGP, SGP4, SGP8, SDP4 & SDP8 and each gives a slightly different Az/EI pointing for the same NORAD data.

—	SGP	the original NORAD algorithm
—	SGP4	applies to Near Earth Orbits
—	SGP8	applies to Near Earth Orbits
—	SDP4	applies to Deep Space Orbits
—	SDP8	applies to Deep Space Orbits

Orbits are differentiated by their period. Those of less than 225 minutes are Near Earth Orbits and those of more than 225 minutes are Deep Space Orbits. Geostationary satellites are in Deep Space Orbit.

It is assumed that the user know which algorithm applies to the data to be used. However INTRAC will not allow a Near Earth Orbit algorithm to be used with Deep Space Orbit data and vice-versa.

The Basic algorithm available in the Rapid Model Generation table is not of NORAD origin. It has none of the embellishments found in the NORAD routines and is meant for test purposes only.



Once the orbital model has been built using the ephemeris data the INTRAC tracks the satellite from it and updates and improves it over the following hours and days.

### **Program Track**

The IESS-412 and NORAD data can also be used by INTRAC to calculate the satellite's path which is then used for a simple Program Track operation.

The selections available in Models - program Track are the same as are available in Rapid Model Generate. On selecting the required algorithm and pressing ENTER the INTRAC enters Program Track mode.

Program Track is an open loop method of tracking and as such is unable to correct for any transducer errors or distortions to the antenna caused by wind.

### **Reserve Model**

Once the orbital model has been built the INTRAC tracks the satellite extremely accurately by continuously monitoring the satellite's position and updating the model. When the beacon signal is not present INTRAC can still track accurately by predicting the satellite's position from the model. However if the beacon signal is lost for more than 72hrs INTRAC deems the model to be no longer valid. In such a situation INTRAC can fall back to a Reserve Model. This is a Program Track model built from either the IESS-412 or the NORAD data. The selection is made in Models - Reserve Model. Assuming the appropriated data has been loaded and is valid INTRAC will automatically fall back to this model when it can no longer predict accurately.

### **Clear Models**

The "Clear Models" menu is used to clear one or more of the INTRAC Model, the IESS-412 Model or the NORAD model. Clearing the INTRAC Model clears the current satellite model. Selecting Auto Continue after this clearing will cause the INTRAC to enter Learning Mode.

Clearing the IESS-412 or NORAD Models simply marks the ephemeris data as being no longer valid. Selecting IESS-412 or NORAD for Rapid Model Generate or Program Track will cause the menu to jump to the Edit IESS or NORAD data menus for new data to be input. Also clearing the data will mean that Reserve Model will not function.

### **Antenna Motion Limits**

There are two methods of limiting the travel of the antenna; a software method and a hardware method. If either type of limit is reached in any direction in an automatic mode a primary alarm is raised, the System Alarm indicator is illuminated and the relevant alarm may be viewed using the Show Alarms menu.

**Soft Limits**

Soft Limits are set in the Configuration - Soft Limits menu. If they are reached in any mode other than Manual an alarm is raised and the INTRAC enters Standby mode.

In either Manual (P) or Manual (A) mode the antenna may be driven through the soft limits with no warning.

**Hard Limits**

Hard limits are physical normally closed contact switches mounted at the maximum points of travel at each end of all driven axes. When the antenna reaches one of these switches the switch becomes open circuit. This open circuit condition breaks power to the motors and (depending on the installed system) signals the INTRAC that a limit has been reached. The removal of drive is such that the antenna cannot be driven any further in the limit direction but can be driven in the opposite direction.

When a limit is reached the INTRAC is automatically put into Standby Mode except when in Manual (P) Mode. In this mode the antenna cannot be driven any further in the limited direction but can be driven in the opposite direction.

**Low Angle Switch**

As well as the Elevation down pre-limit and final limit switches, there is also a low angle limit switch on the antenna. This is a normally closed switch that opens when the antenna goes below an angle currently set to about 4 degrees.

Currently this switch is wired directly to terminals 479 & 459 of the drive cabinet. This is an input to the PLC. In response to this switch the PLC drives an output on terminal 590 which is fed to the INTRAC. The response from the INTRAC is to display a "low elevation" alarm on the alarms page.

The only effect of operating the low angle switch is to activate the alarm message on the the INTRAC alarms page. If it is required to drive an RF cut-off system then the two wires on terminals 479 & 459 should be disconnected from the drive cabinet and taken directly to the RF system. A normally closed set of relay contacts (that open when the cut-off is activated) from the RF system should then be connected to terminals 479 & 459 to activate the alarm message on the INTRAC. Note that 110 Vac is normally present on terminal 479.

**Axes Position**

Resolver units are fitted to the driven axes of the antenna. These units supply positional information to the INTRAC's resolver interface circuits.

Depending on the system "Extended Azimuth" or "EG-01" and/or "Geared Pol" offsets may need to be set.

Fine Tune offsets may be set to calibrate the resolver outputs to the actual antenna pointing angle.

**Tracking Signal**

An L-band Integrated Beacon Receiver (IBR-L) is an option with the INTRAC-605. When fitted this receiver is tuned to an L-band frequency by the INTRAC based on the "Beacon

Frequency" set for the satellite. If the beacon frequency of the satellite to be tracked is not in the L-band a Block Down Converter will be required to convert the signal to L-band. (In some systems this BDC may also be used to convert the traffic signals).

The calculation of the correct L-band frequency for the IBR-L is performed automatically by the INTRAC for BDCs with standard local Oscillator frequencies so that the beacon frequency may be entered at the actual receive frequency.

If an IBR-L is not fitted the INTRAC requires a dc voltage level which is proportional to the received signal strength from the satellite.

## Velocity Drive

The system uses a pair of counter torqued motors for the antenna Azimuth and Elevation drive. When the antenna is not being moved (other than in Standby mode) the power applied to each pair of motors is balanced to hold the antenna stationary. To move the antenna in any particular direction power is increased to one of the motors and reduced to the other. The motor with the increased power drives the antenna whilst the reduced power motor maintains countertorquing to eliminate backlash in the drive mechanism. Once the antenna has reached the required position both motors are again supplied with balanced power and the antenna maintains position.

In Standby mode brakes are applied to hold the antenna stationary and drive to the motors is removed.

### *Motor Drive Speed*

The speed at which the motors drive is continuously variable between 0°/sec and 0.3°/sec. In Goto, Search or Tracking modes the INTRAC ramps up the motor speed to a level dependant on the distance to be moved and ramps down towards the end of the move. In manual mode the speed can be ramped from the INTRAC front panel (the speed in degs/sec being displayed on the screen) or set directly, in degs per second, from a remote control terminal.

In auto modes variable speed CSO is transparent to the user. The INTRAC generates drive signals appropriate for the move required.

### *Manual Drive*

In Manual (P) mode two options are available -

- a) standard two speed manual drive, slow by using the Manual Control keys alone or fast by using them in conjunction with the Latch Drive key.
- b) variable speed drive by selecting the Velocity screen from the Manual screen and using the Manual Control keys to ramp the drive speed.

Velocity Screen

To select the velocity screen press menu key 3 (Velocity) from the Manual mode screen (see below).




Figure 44 - The Manual Mode Screen

The Manual Velocity screen is then displayed –




Figure 45 - The Manual Velocity Screen


Pressing a Manual Control key causes drive in the appropriate direction to increase in speed until the key is released. The speed is displayed against El or Az velocity. When the key is released drive continues at the set speed. Pressing the opposite direction key causes the drive speed to slow until zero speed is reached when drive will commence in the opposite direction. To stop drive press both keys together, i.e., Az right & left or El up & down. Take care to release them both together or drive will re-start in the direction of the key last released!

The drive speed in degrees per second is displayed for both axes, the + & - symbols indicate direction, e.g., + deg/sec for Az Velocity indicates an increasing Az angle.

After the antenna has been driven in Manual Velocity mode the Home screen displayed mode is "Position Hold". This indicates that the antenna is being held stationary by the counter torqued motors rather than by the brakes.

Position Hold

Position Hold mode is entered after a Manual Velocity move, after a Goto move or after a Search instigated from the front panel.



**Figure 46 - The Position Hold Screen**

### Standby


Standby mode causes the antenna brakes to be applied and power to be removed from the motors. Standby is either selected manually by Menu key 1 or selected automatically by a Primary Alarm being raised.

## Redundancy Unit

### Introduction

The INTRAC Redundancy Switch unit is used to select, automatically or manually, one of two INTRAC-605 for control of the antenna. Although only one INTRAC has control of the antenna both INTRACs learn and update an orbit model.

With the front panel switch in Auto the Redundancy Switch Unit arbitrarily selects one INTRAC for control. If the controlling INTRAC fails the Redundancy Unit switches control automatically to the other, good, INTRAC. Control can be forced to either INTRAC by moving the front panel switch to the INTRAC 1 or INTRAC 2 position.



**Figure 47 - The Intrac Redundancy Switch**


The Redundancy Unit has four LEDs, two for each INTRAC. In normal operation both Operational LEDs should be illuminated to show that both INTRACs are working correctly. The INTRAC which has control of the antenna also has its Online LED illuminated.

### Connections

The rear panel connectors of each INTRAC are connected to the Redundancy Unit. The input signals, to the INTRAC, are then connected in parallel before being routed to the Motor

Controller and Resolvers. The motor drive signals of the controlling INTRAC are switched in the Redundancy Unit to the Motor Controller. The resolver source signal is switched from the controlling INTRAC to the resolvers and to the slave INTRAC.

**Figure 48 - The Connections Panel**



The top and bottom row of connectors link to the two INTRACs and the centre row connect to the motor controller. The signals on the Pol, El and Az resolver connectors, on the alarms connector, on the motor control connector, on the Auxiliary 2 connector and on the limits connector are the same as on the same connectors from the INTRAC and are detailed in section 7 of this manual.

**Note** The Auxiliary 1 & 3 connectors from the INTRAC rear panels are each connected in parallel and then taken directly to the motor controller.

The BNC connectors O/P 1 and O/P 2 are the Az & El motor velocity drive signals, the output from the controlling INTRAC being switched in the redundancy unit to the motor controller.

### *Removing one INTRAC from the Dual Redundant System*

If one of the the motor controller.two INTRAC-605s has to be disconnected from the Redundany Unit the emergency stop function of the removed INTRAC will prohibit drive. To enable drive of the one remaining INTRAC the emergency stop circuit of the removed INTRAC has to be linked out.

This is effected by wiring a link across pins 8 & 9 of the 25 way limits connector on the rear of the redundancy unit to which the removed INTRAC was connected.

## 7. CONNECTIONS & SETUP

### Introduction

This section covers the INTRAC-605 rear panel connections and some internal set-up links.

### WARNING

POSSIBLE LETHAL POTENTIALS EXIST WITHIN THIS EQUIPMENT. THE COVERS SHOULD NOT BE REMOVED WHILST POWER IS CONNECTED EXCEPT BY QUALIFIED PERSONS WHO ARE AWARE OF THE ELECTRICAL SHOCK HAZARDS AND WHO HAVE TAKEN ADEQUATE SAFETY PRECAUTIONS.

### Connections Block Diagram




Figure 49 - The Connections Block Diagram

Rear Panel Layout




Figure 50 - INTRAC-605 Rear Panel Layout

All connections to the INTRAC-605 are made via its rear panel. The following connectors are available :-

Remote Port (I/O)	9-way D-type	socket
Test Ports 1 & 2 (I/O)	9-way D-type	sockets
Resolver I/Ps x3	15-way D-type	sockets
Alarm outputs	25-way D-type	socket
Motor Controls Output	25-way D-type	plug
Limits/Status (I/O)	25-way D-type	socket
Auxiliary 1 & 3 (I/Ps)	25-way D-type	socket
Auxiliary 2 (O/P)	25-way D-type	plug
Signal Strength I/P	BNC	socket
Beacon Out-of-Lock I/P	BNC	socket
Signal Strength O/P	BNC	socket
Beacon Signal I/P	N-type (L-band)	socket
Output 1 (EI)	BNC	socket
Output 2 (Az)	BNC	socket




Figure 51 - Redundancy Unit Rear Panel Layout



## Connector Pin Allocations

### Az & EI Resolvers

There are six or ten connections for each of the Az & EI resolvers depending on type. The recommended cable is one with five individually screened twisted pairs. Correctly terminated cables can be supplied by Advantech AMT Limited.

INTRAC™ 605 - Az/EI Resolver Cable Connections				
INTRAC™ 605 Az/EI Resolver Connector		Cable Pairing	Resolver	
15 Way D Type Socket	Signal Name		EG01/RE01	HD001
			MS3106E-18-1S 10 Way Circular Socket	62GB 16 way Circular Socket Number
1	ResSource	1a	A	J
2	AzCoarseSin	2a	F	E
3	AzCoarseCos	3a	G	G
4	ResSource			-
5	AzFineSin	4a		A
6	AzFineCos	5a		C
7	RefIn			-
8	Screen			-
9	Ground	1b	B	K
10	Ground	2b	D	F
11	Ground	3b	E	H
12	Ground			-
13	Ground	4b		B
14	Ground	5b		D
15	Ground			-

**Table 4 – Az/EI Resolver Cable Connections**

The connector genders in the table are those on the units concerned. The connecting cable should thus be terminated in the mating gender.

Recommended cable is Belden 8778 for HD-001 and Belden 8777 for RE01 and EG01 or equivalent.

**Limits**

The cable for the Limits connection should comprise twisted pair cable with an overall screen.

<b>INTRAC™ 605 - Limits Cable Connections</b>			
INTRAC™ 605 Limits Connector		Cable Pairing	Motor Drive Cabinet
25 Way D Socket	Signal Name		Limit Switch Feedback
1	Interlock		
2	Az Final Limit CCW		
3	Az Final Limit CW		
4	EI Final Limit Down		
5	EI Final Limit Up		
6	(Rx) Pol Limit CW		
7	(Rx) Pol Limit CCW		
8	Emergency Stop 1		
9	Emergency Stop 2		
10	(Tx ) Pol Limit CW		
11	(Tx) Pol Limit CCW		
12	Not Used		
13	Screen		
14	Ground		
15	Ground		
16	Ground		
17	Ground		
18	Ground		
19	Ground		
20	Ground		
21	Ground		
22	Ground		
23	Ground		
24	Ground		
25	Ground		

**Table 5 – Limits Cable Connections**

The connector gender in the table is that on the INTRAC. The connecting cable should thus be terminated in the mating gender.

Recommended cable is from the Belden 95nn range or equivalent.

*Motor Control*

The INTRAC-605 outputs low voltage low current motor drive signals to the Motor Drive Cabinet.

INTRAC™ 605 - Motor Control Cable Connections					
INTRAC™ 605 Motor Controls Connector			Cable Pairing	Motor Drive Cabinet	
25 Way D type Plug		Signal Name (SimAx)			
1		Not Used			
2		Not Used			
3		Not Used			
4		Not Used			
5		Not Used			
6		Not Used			
7		Not Used			
8		Not Used			
9		EI Stow Pin I/O			
10		Stow Pin Enable			
11		Not Used			
12		Not Used			
13		Not Used			
14		Not Used			
15		Not Used			
16		Not Used			
17		Not Used			
18		Not Used			
19		Not Used			
20		Not Used			
21		Not Used			
22		Not Used			
23		Not Used			
24		Command Common			
25		Command Common			

**Table 6 – Motor Control Cable Connections**

The connector gender in the table is that on the INTRAC. The connecting cable should thus be terminated in the mating gender.

Recommended cable is from the Belden 95nn range or equivalent.

**Alarms**

The alarm outputs are C form contacts for use by external alarm systems.

<b>INTRAC™ 605 - Alarms Cable Connections</b>		
INTRAC™ 605 Alarms Connector		User Alarm Monitoring System
25 way D type Socket	Signal Name	
1	PriAlmCommon	
2	PriAlmClosed	
3	PriAlmOpen	
4	BeacAlmCommon	
5	BeacAlmClosed	
6	BeacAlmOpen	
7	SecAlmCommon	
8	SecAlmClosed	
9	SecAlmOpen	
10	BeacLevelAlmCommon	
11	BeacLevelAlmClosed	
12	BeacLevelAlmOpen	
13	Ground / Screen	
14	-	
15	-	
16	-	
17	-	
18	-	
19	-	
20	-	
21	-	
22	-	
23	-	
24	-	
25	-	

**Table 7 – Alarms Cable Connections**

The connector gender in the table is that on the INTRAC. The connecting cable should thus be terminated in the mating gender.

Recommended cable is multicore with an overall screen such as Belden 9536 or 9541 (depending on required number of cores).

## Aux 1

<b>INTRAC™ 605 AUX 1 CONNECTOR</b>	
<b>25 Way D Socket</b>	<b>Signal Name</b>
1	Az Brake Released
2	Not Used
3	Not Used
4	El Brake Released
5	El Stow Pin In
6	El Stow Pin Out
7	Az Prelimit CW
8	Az Prelimit CCW
9	El Prelimit Up
10	El Prelimit Down
11	Az Stow Pin Aligned
12	El Stow Pin Aligned
13	Screen
14	Ground
15	Ground
16	Ground
17	Ground
18	Ground
19	Ground
20	Ground
21	Ground
22	Ground
23	Ground
24	Ground
25	Ground

Table 8 – AUX 1 Connector

## Aux 2

<b>INTRAC™ 605 AUX 2 CONNECTOR</b>	
<b>25 Way D Socket</b>	<b>Signal Name</b>
1	Vel EN Az
2	Vel EN EI
3	Not Used
4	Not Used
5	Not Used
6	Not Used
7	Not Used
8	Not Used
9	Not Used
10	Not Used
11	Not Used
12	Not Used
13	Ground
14	INTRAC Common
15	INTRAC Common
16	Not Used
17	Not Used
18	Not Used
19	Not Used
20	Not Used
21	Not Used
22	Not Used
23	Not Used
24	Not Used
25	Ground

Table 9 – AUX 2 Connector

## Aux 3

INTRAC™ 605 AUX 3 CONNECTOR	
25 Way D Socket	Signal Name
1	Az Drive Alarm 1
2	Az Drive Alarm 2
3	EI Drive Alarm 1
4	EI Drive Alarm 2
5	Low Angle
6	Not Used
7	Not Used
8	Not Used
9	Not Used
10	Not Used
11	Not Used
12	Not Used
13	Screen
14	INTRAC Common
15	INTRAC Common
16	INTRAC Common
17	INTRAC Common
18	INTRAC Common
19	Ground
20	Ground
21	Ground
22	Ground
23	Ground
24	Ground
25	Screen

Table 10 – AUX 3 Connector

**Serial Ports**

There are three serial ports on the INTRAC-605, "Remote Port", "Test Port 1" and "Test Port 2". Each can be independently configured as either RS423 or RS422.

The pin allocations for both are given in the tables below.

<b>INTRAC™ 605 Serial Port Connections (RS423)</b>				
INTRAC™ 605 Serial Port Connector		Signal Name	Remote Control PC	
9 way D type Socket	Signal Type		Signal Type	PC Connector
1	Passive	DCD		
2	output	RXD	input	
3	input	TXD	output	
4	-			
5	GND	GND	GND	
6	Passive	DSR		
7	-			
8	Passive	CTS		
9	N/C		N/C	

**Table 11 – Serial Port Connections (RS423)**

<b>INTRAC™ 605 - Serial Port Connections (RS422)</b>				
INTRAC™ 605 Serial Port Connectors		Signal Name	Remote Control PC	
9 way D type Socket	Signal Type		Signal Type	PC Connector
1				
2	output	RXDB = RXD-	input	
3				
4				
5	GND			
6	output	RXDA = RXD+	input	
7				
8				
9				

**Table 12 – Serial Port Connections (RS422)**

The INTRAC-605 is wired as a DCE unit suitable for direct 1 to 1 connection to the 9-way serial port of a PC AT.

TXD and RXD data flow directions are standard (relative to the DTE). Handshake lines are pulled to the ON condition.

The factory default setting for the three serial ports is RS423. How to set to RS422 is shown on the next page.





*Serial Port RS422/423 Setting*

Setting the Serial Ports to RS422 or RS423 is achieved by positioning the rear panel ribbon cables and by link positions. The table below shows the positions.

<b>INTRAC™ 605 Serial Port Configuration - Connector &amp; Link Positions</b>				
INTRAC-605 Serial Port	RS423		RS422	
	Ribbon Cable position.	Link Position	Ribbon Cable position.	Link Position
Remote Control Port	J13	J48 Front	J16	J48 Rear
Test Port 1	J12	J44 Front	J15	J44 Rear
Test Port 2	J11	J46 Front	J14	J46 Rear

**Table 13 – Serial Port Configuration (Connector & Link Positions)**

*Serial Port Usage*

The three ports can be used to connect a Remote Control Terminal, to monitor diagnostic data or to monitor angle data. The specific uses for each port are:-

*Remote Port*

A Remote Control and Monitoring Terminal may be connected to this port.

Diagnostic data can be monitored by selecting "Diagnostics On" in the "Function - Configuration" menu. Remote control of the INTRAC is achieved only if "Diagnostics Off" is selected in the Configuration menu.

*Test Port 1*

Diagnostic data is also available at this port together with Angles data. The selection between Diagnostics and Angles is made by Menu Key 4 on the "Function - Configuration" menu. The key switches between "Test Port-1 Diags" and "Test Port-1 Angles"

*Test Port 2*

This port is for the umbilical handheld remote control terminal only.

The Remote Port allows one PC to be used as a remote control unit and as a diagnostics monitoring unit. However it cannot do both at the same time.

**Note**

**For correct remote control of the INTRAC-605 via the Remote Port Diagnostics must be set to OFF.** Diagnostic data can be monitored during remote operation by using a second PC connected to Test Port 1.

### *Tracking Signal Connections*

#### *Beacon Signal Connector*

When an IBR-L beacon receiver is fitted there will be a "N-type" RF connector on the INTRAC rear panel. It is to this that the beacon signal is connected.

#### *Note*

18Vdc may be connected to the inner connector of the N-type in order to power the Block Down Converter. It may then be necessary to have a dc block before the LNA if it will be affected by the dc voltage.  
The 18V can be removed from the connector by link J41 on the INTRAC Interface board.

#### *Signal Strength Output*

When an IBR-L beacon receiver is fitted a dc voltage proportional to the received beacon signal strength expressed in dB is available on a BNC connector on the INTRAC rear panel.

#### *Signal Strength Input*

Where no IBR-L is fitted the INTRAC-605 requires a dc voltage generated by an external receiver. This voltage must be directly proportional to the received signal strength in dB. The signal strength input is via a BNC connector on the INTRAC rear panel.

#### *Out of Lock Input*

When an external receiver is used to provide the tracking signal a receiver out of lock signal may be provided to indicate to the INTRAC that the tracking signal is no longer valid. This signal should be provided by a pair of relay contacts which close to indicate loss of lock.

### **CSO Drive Outputs**

#### *Output 1*

The BNC connector Output 1 is the CSO drive voltage output for the Elevation axis. The voltage range is +/- 10v the higher the voltage the faster the drive. A positive voltage drives upwards.

#### *Output 2*

The BNC connector Output 2 is the CSO drive voltage output for the Azimuth axis. The voltage range is +/- 10v the higher the voltage the faster the drive. A positive voltage drives to the right.

**Resolvers**

The RE-01, EG-01 and bare size 11 resolvers are capable of continuous rotation. However the HD-001 resolver may only be rotated through 340°. It will be damaged if rotated through more than 340°.

*Fitting to the Antenna*

Exactly how the resolvers are fitted to the antenna depends on the antenna concerned. However either the shaft or the body of the resolver has to be coupled directly to the Az, El or Pol rotational axis and that part of the resolver which is not coupled to the rotational axis has to be very firmly fixed to a non moving surface.

For the coupling between the resolver shaft and the antenna axis we recommend a flexible “bellows” type coupler which allows for some miss-alignment between the shafts but does not introduce any backlash or windup.

*Setting up*

Put the INTRAC into Manual Mode.

Determine in which direction each resolver shaft will rotate, viewed from the faceplate of the resolver, for an increasing angle of antenna pointing. In the Function - System Setup - Fine Tune - Sense menu the resolver sense can be set to “true” or “inv”. If the shaft rotates clockwise for an increase in the angle set the appropriate (Az / El / Pol) sense to “inv”, if the shaft rotates counter clockwise for an increase in the angle set the sense to “true”.

Zero the Fine Tune - Offsets.

Ensure that the antenna is away from the hardware limit switches. Determine the actual pointing angles of the antenna. The Elevation angle should be between 0° and 90°. The Azimuth angle should be between 90° (E) and 270° (W) via 180° (S) (for the Northern Hemisphere) or between 270° (-90°) and +90° via 360° / 0° (N) for the Southern Hemisphere. The Polarisation angle should be between -90° and +90°.

Loosen the couplings between the resolver units and their respective antenna shafts. Rotate each resolver shaft slowly until the INTRAC displayed Az, El and Pol angles are as near as possible to the actual angles of the antenna.

**Note**

If a resolver angle is, or becomes, outside the software limits an alarm will be raised. In this situation the software limits may be set wider.

When the displayed angles are as near as possible (at least within 10°) to the actual angles tighten the resolver couplings ensuring that the angles remain as set.

Use the Fine Tune - Offsets facility to change the displayed angles to the actual antenna angles.

**Southern Hemisphere**

Set-up in the Southern Hemisphere is the same as for the Northern Hemisphere except that the antenna rotation will be  $\pm 90^\circ$  of North instead of  $\pm 90^\circ$  of South. Selection of Southern or Northern Hemisphere within the INTRAC is automatic based on a positive or negative input for Latitude in System Setup - Station Co-ordinates.

**Tracking Signal Input**

The tracking signal may be provided as a dc voltage from an external receiver or from the optional IBR-L internal receiver.

*With IBR-L*

The IBR-L requires a L-band beacon signal at a level within the range -80dBm to -45dBm with a carrier to noise ratio (C/No) of better than 40dBHz. To allow some margin for exceptional propagation conditions we suggest that the normal clear sky level when peaked on the satellite should be in the range -70dBm to -50dBm. Severe signal fades will be handled by the INTRAC algorithm entering Prediction mode for the duration of the fade.

If the signal is greater than -50dBm attenuation must be inserted and if it is lower than -80dBm a higher gain LNA/LNB must be used.

An input level of -45dBm corresponds to a displayed level of +25dB.

**Note**

In some installations the LNA/LNB power is carried on the L-band signal cable and special arrangements have to be made to ensure continuity for the dc power when attenuation is added in this cable.

*Without IBR-L*

The tracking signal, provided from an external receiver, needs to be a dc voltage between -10v and +10v. This voltage should vary proportionally (in dBs) with the received signal strength.

The INTRAC can be adjusted for a fixed offset and a proportionality constant between 0.1v/dB and 1.0v/dB in either polarity.

*Setting offset & gain*

Connect a switchable attenuator in the IF feed to the tracking (beacon) receiver.

Connect the dc tracking signal to the INTRAC Signal Strength Input BNC.

Remove the top cover to the INTRAC-605.

Link J31 and potentiometers R12 & R55 are used in the set-up.

Link J31 can be changed for -ve or +ve polarity signals.

R12 adjusts the gain of the tracking signal buffer.

R55 adjusts the offset.

Set the switchable attenuator to 0 dB.

Adjust R55 so that the signal level displayed on the INTRAC-605 is between -10dB and +20dB.

Adjust R12 so that 2dB attenuation of the receiver IF signal causes the displayed signal to decrease by 2.0dB.

Finally adjust R55 to read +20dB when the maximum clear sky tracking signal is being received.

**Note** It may be necessary to adjust the links J31 depending on the polarity of the tracking signal. The link options are both links should be either vertical or horizontal.

## Operational Checks

### *Manual Operation*

This test checks the operation of the motor drives and limit switches.

Ensure that all limit and interlock switches are in the normal operating condition.

Switch on the INTRAC. If the System Alarm indicator illuminates press the Standby key. If it remains illuminated view the Show Alarms display to what is causing the alarm. Take the necessary action to clear the cause(s) of the alarm.

Select Manual (P) Mode from the New Mode menu.

Using the Manual Control keys drive the antenna to the full extent of its travel in each direction. Confirm that the antenna actually moves in the required direction. Check that when a limit switch is reached the motor stops and the System Alarm indicator illuminates.

**Note** Only one Manual Control key should be pressed at one time and it should be fully released before pressing another control key.

If a Dual Speed Motor Drive Cabinet is fitted check that the "FAST" key operates correctly. Pressing the "FAST" key when pressing a Manual Control key should latch fast drive in the required direction. Pressing any Manual Key when in latched Fast Drive should have no effect. Pressing the Fast key again should remove drive.

### *Emergency Stop Check*

Check the operation of the front panel Emergency Stop switch by pressing it when one or more motor's is running. Ensure that the motor(s) stop and will not re-start until the Emergency Stop switch is released and the appropriate drive command re-instated.

If external emergency stop switches are fitted check their operation in the same way.

It must not be possible to re-start any motor whilst any emergency stop switch is in the operated state.

*Auto Operation*

After manually pointing the antenna towards the required satellite use the Search facility to peak the antenna on the satellite. Check that this function works correctly. Select Auto New Model and check that INTRAC enters Learning Mode and makes periodic cross scans interspersed with pointing adjustments. Check that after 24 hours of Learning the INTRAC enters Tracking Mode.

*Remote Control*

If a Remote Control and Monitoring Terminal (RCM-4) package has been supplied check that this works correctly (see section 10 for an explanation of the RCM-4).





## 8. FAULT FINDING

### **WARNING**

#### **POSSIBLE LETHAL POTENTIALS EXIST WITHIN THIS EQUIPMENT**

THE COVERS SHOULD NOT BE REMOVED WHILST POWER IS APPLIED  
EXCEPT BY QUALIFIED PERSONNEL WHO ARE AWARE OF THE PRECAUTIONS  
THAT SHOULD BE TAKEN TO PROTECT AGAINST ELECTRIC SHOCKS

### **Introduction**

Advantech AMT Limited recommend that users return faulty INTRAC-605 units to Advantech for repair. Advantech have a specially equipped repair facility and are able to repair and return a unit rapidly if required. However if the problem is of an intermittent nature it may be beneficial to allow us to soak test the unit for a longer period. A replacement unit may be available from Advantech during the repair period. Please ask for details of this service.

Repairs carried out by Advantech are warranted for 90 days.

For those users who would prefer to repair their own unit this section is intended to help with the location of faults.

**However :-**

**ADVANTECH AMT LIMITED ACCEPT NO RESPONSIBILITY OR LIABILITY FOR ANY HARM CAUSED TO ANY THIRD PARTY PERSONNEL FROM WORKING INSIDE THE INTRAC-605.**

**ADVANTECH AMT LIMITED ACCEPT NO RESPONSIBILITY OR LIABILITY FOR ANY DAMAGE CAUSED TO THE INTRAC-605 BY ANY THIRD PARTY PERSONNEL AS A DIRECT OR INDIRECT RESULT OF THIS SECTION OF THIS MANUAL.**

**ANY THIRD PARTY WORK INSIDE THE INTRAC-605 DURING THE WARRANTY PERIOD WILL INVALIDATE THE WARRANTY**

Because the INTRAC-605 forms part of a system, parts of which respond to signals from the INTRAC-605 and parts of which send signals to the INTRAC-605, deciding whether a fault lies with the INTRAC-605 or the external equipment can be difficult.

The simplest method to prove if the fault lies with the INTRAC-605 or some other equipment is to replace the INTRAC with a spare unit. However care must be taken in such a case that any fault with the external equipment does not cause damage to the replacement INTRAC. Also you must ensure that the replacement unit is set correctly for the installation.

This fault finding guide goes no further than the replacement of the major assemblies such as power supply, IBR-L or complete printed circuit assemblies.

The INTRAC-605 consists of six major assemblies :-

- Main Interface PCB
- Processor PCB
- Low voltage power supply
- LCD Display panel
- Front panel keys assembly
- Beacon receiver (optional)

**Note** The LCD display panel has a replaceable backlight which has a finite life span. This light will need replacing within the working life of the INTRAC-605. Included in this section are instructions on replacing the lamp.

## Fault Symptoms

### *INTRAC Doesn't Appear To Power Up*

Check that the main power-on switch glows green when switched on. If not check INTRAC fuse, power cable and power source

*Display Screen Blank/Dark* Data is visible on screen but display is very dark.

Try to adjust display brightness and contrast. Contrast adjustment has some effect but brightness has none. LCD backlight or its inverter has failed.

**Note** To adjust brightness or contrast press menu keys 2 - 4 - 5 followed by the Enter key. Menu key 4 will now control brightness and menu key 3 will control contrast.

Display is bright but there is no data visible. Brightness control has some effect but contrast does not.

Check power supply voltages :-

- |                         |   |   |
|-------------------------|---|---|
| — V1 = +5v to com       | ) | Voltages should be within 5% of stated values |
| — V2 = +15v to com      | ) |   |
| — V3 = 12v across + & - | ) |   |
| — V4 = 24v across + & - | ) |   |

If voltages are correct fault is with LCD, ribbon cable to J18 (Interface PCB) or the Interface PCB itself.


*Replacing The LCD Backlight*

Remove the top cover from the INTRAC-605. The rear of the LCD panel is then visible.

Disconnect the two lamp wires from the orange connector at the front corner of the Interface PCB. Disconnect the LCD panel flex cable from Connector J64 on the Interface PCB.


Remove the four screws which hold the INTRAC front panel to the sides and drop down the front panel. Remove the four nuts which hold the display assembly to the front panel and remove the display unit from the front panel. Lay it face down on a soft surface.

Press down on the centre of the two retainers (see diagrams)



Turn the display face up. Remove the retainer pins. Remove the metal cover.

Turn the display face down on a soft surface. Gently slide the backlight unit from the display unit. (see diagram)



Remove the three tapes which secure the lamp reflector. Remove the lamp and wire assembly.

Install new lamp and wire assembly.  
Wrap reflector sheet around lamp.  
Replace securing tapes to secure reflector.  
Turn unit face up and ensure that backlight is free from contamination - dust may be blown free.  
Slide backlight into display unit.  
Replace metal cover over backlight.  
Replace retainers, press centre to secure.  
Locate display unit over the four studs and fit the nuts.  
Re-fit INTRAC front panel to side panels, reconnect flex cable and lamp wires.  
Replace INTRAC top cover, reconnect power, switch on and verify that the lamp illuminates.

*Front Panel Keys Do Not Function*      Some, or all, front panel keys do not function.  
The six menu keys, the numerical keypad and the manual control keys are all connected in a matrix. There are three supply lines to the matrix and eight return lines. If any one of these lines fails at least three keys will cease to function. The fault may be the ribbon cable to J27 (Interface PCB), the connectors or the Interface PCB itself.

If only one key does not function the fault will be with that key and the front panel PCB will have to be replaced. This board is held on the front panel by six threaded studs. Disconnect the ribbon cable and the emergency stop switch (note which wire goes to which terminal). Remove the six nuts and lift the PCB off the studs.

*Emergency Stop Switch Fails*      Pressing the front panel emergency stop switch should cause the System Alarm indicator to illuminate and the INTRAC to enter Standby Mode.

The switch consists of two normally closed (N.C.) contacts pressing the switch opens both sets of contacts. The switch connects to the Interface PCB through the front panel PCB and the ribbon cable. If the switches are OK and there is continuity to connector J27 on the Interface board the fault is on that board.

*Pointing Angles Incorrect*      The resolvers consist of three coils two of which move with respect to the third. A continuous signal is sent from the INTRAC to the fixed coil and is induced into the other two coils. The amount of induction in each coil is dependant on the respective position of the coils.  
The signal sent from the INTRAC is the same for all resolvers.

<i>angles constantly varying</i>	<p>Constantly changing angles is caused by noise on the two return signal lines. This implies that the source signal is not present in the resolver. For one angle (ie Az, El or Pol) to be changing either the circuit to the resolver is broken or the resolver itself is faulty.</p> <p>If all the angles are changing the fault is on the Interface PCB.</p>
<i>wrong angle displayed</i>	<p>If the displayed angle changes to be near 0° or 90° it is probable that one of the two return signal circuits from the resolver is broken or the resolver itself is faulty.</p> <p>If the displayed angle changes to any angle other than near 0° or 90° the fault is on the Interface PCB.</p>
<i>angle doesn't change when antenna is moved</i>	<p>If the displayed angle doesn't change when the antenna is being driven first ensure that the antenna is actually moving in the relevant plane.</p> <p>Select Manual Mode and drive the antenna in the appropriate direction and either check that the beacon level changes or actually look at the antenna.</p> <p>If the antenna is moving and the displayed angle is not changing the problem is the connection of the resolver to the antenna.</p>
<i>No Antenna Drive</i>	<p>Check that the LEDs in the Manual Control keys illuminate when antenna drive is commanded. If not the fault is on the Interface PCB.</p> <p>The Motor Controls connector (25-way D-type) on INTRAC rear panel should have +24v on pins 14 to 25 measured with respect to pin 13 (Gnd). The drive signals are on pins 1 to 12 and are from open collector transistors which pull down to drive. Thus 24v should be present across the appropriate pin (1 to 12) and any pin 14 to 25 when the relevant drive command is given.</p> <p>Each drive signal has two opposite functions such as on/off, up/down, left/right and so on. One function occurs when the signal is on and the other when it is off.</p> <p>The two tables below indicate which signals are on for which antenna movement. The first table is for single axis drive and the second for simultaneous axis drive.</p> <p>An X indicates an energised signal, thus that pin should be pulled down to (near) zero volts and 24v should be measured between it and the 24v pins.</p>

Single Axis Drive Systems

Direction & Speed	Drv Select	Az	Fast	Up/Rt	Pol Select	Pol Cw
	pin 1	pin 2	pin 3	pin 4	pin 7	pin 8
Left/Slow	X	X	O	O	O	O
Left/Fast	X	X	X	O	O	O
Right/Slow	X	X	O	X	O	O
Right/Fast	X	X	X	X	O	O
Up/Slow	X	O	O	X	O	O
Up/Fast	X	O	X	X	O	O
Down/Slow	X	O	O	O	O	O
Down/Fast	X	O	X	O	O	O
PolCw	O	O	O	O	X	X
PolCcw	O	O	O	O	X	O

Simultaneous Axis Drive Systems

Direction & Speed	EI Select	EI Up	EI Fast	Az Select	Az Right	Az Fast	Pol Select	Pol Cw
	pin 1	pin 2	pin 3	pin 4	pin 5	pin 6	pin 7	pin 8
Left/Slow	O	O	O	X	O	O	O	O
Left/Fast	O	O	O	X	O	X	O	O
Right/Slow	O	O	O	X	X	O	O	O
Right/Fast	O	O	O	X	X	X	O	O
Up/Slow	X	X	O	O	O	O	O	O
Up/Fast	X	X	X	O	O	O	O	O
Down/Slow	X	O	O	O	O	O	O	O
Down/Fast	X	O	X	O	O	O	O	O
Pol Cw	O	O	O	O	O	O	X	X
Pol Ccw	O	O	O	O	O	O	X	O

*example* SimAx System - Elevation Up Fast - there should be (near) 24v between pins 1 & 14, 2 & 15 and 3 & 16.  
See Section 7 - Installation - Connector Pin Allocation - Motor Control.

If the drive signals from the INTRAC are correct the fault lies with the Motor Drive Cabinet, the antenna drive motors or the intervening wiring.

For details of the Motor Drive Cabinet see the appropriate attached appendix (see Appendices Contents).

*Tracking Signal (IBR-L)*

If the beacon signal falls to a non-usable level the INTRAC automatically enters Predicting Mode and continues to track the satellite from the model. There is no way of knowing from the INTRAC whether the loss of signal is due to the satellite or the IBR-L. Thus when the displayed beacon level falls below normal the user should check the signal by some other means before assuming an IBR-L problem. The beacon should be checked with a spectrum analyser on a narrow sweep range so that the actual beacon frequency can be seen and measured.

Although the loss of or reduction in displayed beacon level could be caused by a fault on the Interface PCB the most likely cause is a faulty IBR-L.

Deliberately left blank



## 9. WARRANTY & REPAIR

### Warranty

Advantech AMT Limited warrants the INTRAC-605 Antenna Control Unit, the (optional) IBR-L integral L-band beacon receiver and other associated products designed, manufactured and supplied by Advantech AMT Limited for a period of 365 days from the date of delivery.

The liability of Advantech AMT Limited under this warranty shall be limited to repair or replacement of defective units or parts thereof, at Advantech AMT option, which are returned ,carriage and insurance paid, to 39 Edison Road St.Ives, Cambridgeshire PE27 3LF England. The returned unit(s) must be accompanied by a document declaring that the equipment is returned for repair under warranty and describing clearly and fully the reason for the return of the unit. Subject to the unit being eligible for warranty repair Advantech AMT Limited will effect the repair and return the unit by pre-paid shipment to the originating location. Subject to the shipment charges being the same as, or less than, that to the original location the unit may be shipped to some other location as the customer may specify.

Under no circumstances shall Advantech AMT Limited be liable for any consequential or incidental costs or damage.

### *Exclusions*

This warranty does not apply to any equipment which has been damaged through abuse, accident (such as lightning strike), negligence or failure to comply with Advantech's instructions for storage, installation and use as contained in the equipment manual(s).

Except as specifically provided above Advantech makes no warranties, expressed or implied, as to the merchantability or fitness for a particular purpose.

### Repair Service

Advantech AMT Limited will provide a repair service for all equipment manufactured by Advantech for a period of ten (10) years.

### *Returning equipment for repair*

Prior to the return of any equipment for repair, whether under warranty or by payment, Advantech AMT Limited must be contacted. The purpose of this contact is to discuss the problem and confirm that equipment needs to be returned. Also to agree the most effective solution to the problem and to discuss the method of return in order to avoid unnecessary duties and ensure that the packing is adequate to protect the equipment during shipment.

### *Repairs not under warranty*

The cost of returning the equipment to Advantech AMT Limited will be paid by the customer.

Repairs to equipment not under warranty will be paid for by the customer. On receipt of the defective unit Advantech AMT

Limited will investigate the fault, determine the most effective repair technique and issue a repair cost estimate.

Repair work will not commence until the cost is authorised by the customer either by a Purchase Order or through a Repair Contract.

In certain circumstances repairs may be carried out on site by prior agreement.

*Documentation*

On completion of the repair the unit(s) will be returned to the customer together with a Repair Report and a repair contact name at Advantech AMT Limited.

*Return shipment*

The repaired unit(s) will be returned to the originating location with Advantech AMT Limited bearing the cost of shipment and in transit damage or loss.

The equipment may be returned to some other location at the request of the customer subject to the shipment cost being the same as, or less than, that to the original location.

Invoices for repairs not covered by a warranty will be issued at the time the equipment is despatched. The Invoice(s) is/are payable within 30 days.

*Warranty of repairs*

Advantech AMT Limited will warrant the repaired unit, in respect of the work and material of the repair, for a period of ninety (90) days from the date of return of the unit to the customer. However where the remaining time of the standard warranty exceeds 90 days the repaired unit will be warranted for that remaining period.

NOTE

Advantech AMT Limited reserves the right to charge for rectification of any faults caused as a result of attempts to repair equipment by third parties.

## 10. REMOTE CONTROL TERMINAL

### Introduction

The RCM-4 is a Remote Control and Monitoring software package for an IBM PC or compatible. It provides an easy to use remote control unit for one or more INTRAC systems.

The software runs under Windows 95 or 3.x. Minimum hardware requirements are a 386SX processor, 4 Mbytes of RAM, 1.44 Mbyte floppy disk drive, 10 Mbytes of free hard disk space and a serial "COM" port.

The software is supplied on one 1.44 Mbyte floppy disk.


### Installation & Set-up

#### *Installing the software*

With Windows running insert the program disk into the floppy drive. From the File Manager select the File drop down menu and click on RUN. Type in a:\setup (assuming disk is in drive A). Setup will commence and ask if installation should be to C:\RCM. Choose continue, select the full installation at the prompt. Setup will create a directory RCM under C: and copy RCM.EXE and RCM.HLP to it. Two antenna directories will also be created Antenna 1 and Antenna 2 these will have sub-directories into which files will be copied. Files will also be copied to the C:\Windows\System directory.

When setup is complete there will be a folder in the Program Manager named RCM inside which will be two icons named RCM Ant1 and RCM Ant2. These are intended for antennas connected to the COM1 and COM2 ports of the PC.


At this point there will be the following directory structure :-




The files STATION.DAT, SATNAME.DAT & MANUAL.DAT files will need editing to match the station and satellites of interest for the antennas. This editing can be done from within the RCM program.

**Configuring the RCM-4**


Double click on the RCM Ant1 icon in the RCM folder.



This is the main screen of the RCM-4. If communications between the RCM and the INTRAC are working the screen will appear similar to above. If the comms are not working the EI & Az values will be zero and the mode will be unknown! Also, within a few seconds, the following screen will appear.



To change the PC Com port and baud rate click on the Comm Settings box.



This small overlay screen appears and the Comm port and line speed can be set. When set correctly click on OK which closes the overlay screen. Click on "Try Again" on the Comms Failure screen. Assuming comms are now OK the main screen is displayed.

From the Main screen click on the Function box.

**DEMO STATION - Functions**

Freq: 1.5GHz  
Level: 0.00dB  
El: 29.482°  
Az: 180.521°  
Auto [Learning]

**Function**

- ☒ RCM Config
- ☐ INTRAC Config
- ☐ Stow
- ☐ Limits, Time & Frequency
- ☐ Ephemeris Data

OK  
Return  
Standby

Clicking on OK selects the function with the dot in the circle to its side. The dot defaults to RCM Config on entering the Functions screen. Click on OK.

**DEMO STATION - RCM Config**

Freq: 1.25GHz  
Level: 0.07dB  
El: 29.877°  
Az: 180.115°  
Pol: 0.000°  
Auto [Learning]

Edit Comms Configuration  
Edit Station Parameters

**Pol**

- ☐ Unavailable
- ☒ Available

**Display Resolution**

- ☐ 1 dec. place
- ☐ 2 dec. places
- ☒ 3 dec. places

**Beacon Band**

- ☒ L-Band
- ☐ C-Band
- ☐ X-Band
- ☐ Ku-Band 1
- ☐ Ku-Band 2
- ☐ Ku-Band 3
- ☐ Ku-Band 4

OK  
Return  
Standby

From this screen the number of displayed decimal places, the frequency band of the satellite's beacon signal and whether motorised polarisation is available are set. Click in the appropriate circles and then on OK.

## Configuring the INTRAC

From the Functions screen select INTRAC Config by clicking on it and then clicking on OK.

**DEMO STATION - INTRAC Config**

Freq: 1.25GHz  
Level: 0.10dB  
El: 29.817°  
Az: 180.214°  
Pol: 0.000°  
Auto [Learning]

**Fine Tune Offsets**

El: 0.000°  
Az: 0.000°  
Pol: 0.000°

**Reserve Mode**

- ☐ IESS-412
- ☐ NORAD

**Stow Angles**

El: 31.998° Az: 182.999°

OK  
Return  
Standby

The Stow position, Fine Tune Offsets and the Reserve Model source can be set from this screen. However the Stow position and Offsets would normally have been set at the INTRAC during installation.

### The RCM.INI file

Below is an example of the RCM.INI file which is used to set the various parameters of the remote control facility.

```
[RCM]
SatelliteDirectory=DEMO
PortNo=1
PortSettings=9600,N,8,1
PortType=MSCOMM
FrequencyBandType=0
External_Az_Display=0
External_EI_Display=0
FrequencyBand=0
PolAvailable=0
DisplayRes=1
ToggleRepeat=1
AlarmLog=OFF
BeaconPolSelect=OFF
CSOEnable=ON
ExtendedAz=OFF
newNamePromptEnable=OFF
PauseAfter8messages=OFF
WinLeftPosition=4020
WinTopPosition=1500
FrequencySubBand=1
```

The RCM.INI file is used to set various parameters for the RCM. Some of these parameters, such as FrequencyBand and PolAvailable, can also be set from within the RCM. Others, such as BeaconPolSelect and ExtendedAz, can only be set in the .INI file.

**Note** The .INI file only sets the RCM parameters. The INTRAC must also be set from the front panel in Local Mode.


The various parameters in the .INI file are described in RCM Help. The parameters which affect operation of the system are also described at the end of this section.

Those parameters are :-


- BeaconPolSelect
- CSOEnable
- ExtendedAz
- newNamePromptEnable

## Setting the Satellite Data

To set/edit the data associated with Antenna 1 double click on the RCM Ant1 icon in the RCM folder. This will bring up the RCM window for antenna 1.



Select RCM Config and click on OK. The RCM Config screen is then displayed. Click on the Edit Station Parameters box.



This invokes the Notepad editor with the STATION.DAT file for this antenna. The file consists of three lines of text. The first line is for the Station Name which will be displayed in the top bar of the RCM screen. The second line contains the Latitude, Longitude and Height of the Station and the third line is for the Az & El Offsets of the antenna mount.

When the editing is complete click on the close box and save the file at the prompt. This returns you to the RCM Config screen. Click on the Return box to the Functions screen and Return again to get to the main screen.

## Setting Satellite name

The Satellite name is stored in a file "SATNAME.DAT". To edit this file select Ephemeris Data from the Functions screen. The following screen appears.

The screenshot shows a dialog box titled "DEMO STATION - Ephemeris Data, Select Satellite". On the left, there are input fields for "Freq:" (1.25GHz), "Level:" (-0.73dB), "El:" (29.877°), "Az:" (180.214°), and "Pol:" (0.000°), with a "Standby" button below them. On the right, there is a "Satellite Directory:" dropdown menu set to "DEMO", an "IBR-L Frequency:" field set to "1.25GHz (L-Band)", and a "Satellite Name:" field containing "Demo Sat". Below these are "Add", "Delete", "Move To", and "Edit" buttons. To the right of the "Satellite Name" field is a "Valid Data Files" section with four checkboxes: "Nominal Position", "IESS-412", "Transfer", and "NORAD", all of which are checked. At the bottom right are "Return" and "Standby" buttons.

Click on the Edit box.

The screenshot shows a dialog box titled "DEMO STATION - Edit Data". On the left, there are input fields for "Freq:" (1.25GHz), "Level:" (-1.06dB), "El:" (29.877°), "Az:" (180.214°), and "Pol:" (0.000°), with a "Standby" button below them. On the right, there is an "Options" section with five radio buttons: "Create/Edit Data File" (selected), "Copy Ephemeris Data", "Get Transfer Data", "Load IESS Data", and "Load Transfer Data". To the right of the "Options" section are fields for "Directory:" (DEMO), "Satellite:" (Demo Sat), and "File:" (FREQ.DAT). At the bottom are "OK", "Return", and "Standby" buttons.

Select Create/Edit Data File. Click on the down arrow on the right side of the screen to drop down the list of files.

Select SATNAME.DAT and click on the OK box. This invokes the Notepad editor with SATNAME.DAT file. All that is in this file is the satellite name. Create or edit it as for the station data.

Antenna 2 station and satellite names are set in the same manner. Click on the RCM Ant2 icon to commence.

**Note** STATION.DAT is specific to each antenna thus the antenna designation may be use in stead of or as well as the station name.


## Adding Satellites

Other satellites may be added to each antenna by selecting Add instead of edit on the Ephemeris Data, Select Satellite screen.



The add satellite consists of three entries. Satellite Directory, enter a name not already in use. Satellite Name, enter the name for the satellite. IBR-L Frequency, enter the beacon frequency of the satellite. Click on OK. This will create the directory and the files SATNAME.DAT and FREQ.DAT. Before this new satellite can be used a MANUAL.DAT file is required. This file contains the Az and El angles for the antenna.

Use the Copy Ephemeris Data facility from the Edit Data screen to copy the MANUAL.DAT file from the original Satellite to the new one. Then use the edit facility to change the AZ & El co-ordinates.



The copy facility allows files to be copied to or from the selected satellite directory. The other directory can be selected via the drive, directory, file selection boxes in the top right of the screen.


The RCM-4 is now ready to be used .

To make the RCM-4 program start automatically on PC power on drag the required icons from the RCM folder to the STARTUP folder and exit Windows by pressing Alt+F4. When Windows is invoked again the required RCM should start automatically. To enable an automatic start from power on the AUTOEXEC.BAT file must invoke Windows.

Using The RCM-4

This section assumes that the RCM-4 has been set-up to start automatically on powering on the PC and that the INTRAC is set for remote control.

Power on the PC and the following screen will be displayed.



This screen is the main screen of the RCM-4 and shows the pointing angles of the antenna, the satellite beacon frequency, the tracking signal level and the INTRAC Mode.


There are four software switches on the right of the screen with which the INTRAC can be put into Standby, any Alarms can be viewed or the INTRAC's various Modes and Functions can be accessed.

Note If there are any Primary Alarms set the word Alarm will be red otherwise it will be green.

Every screen other than the main screen consists of two parts. The left third of the screen remains the same for all screens whilst the right two thirds displays the screen's function.


The left side of each screen displays the satellite name, the beacon frequency, the tracking signal level, the antenna pointing angles and the INTRAC Mode.

This display is the same as the top part of the INTRAC's front panel display.



## Alarms

Clicking on the Alarms box (Main screen) brings up the Alarms screen. When there is an Primary Alarm active the word Alarm in the box is red and there is an audible warning. The audible warning is disabled whilst the alarm screen is displayed.




This screen shows all active alarms both Primary and Secondary. After the cause of an alarm has been removed it is necessary to click on Standby to clear the alarm indication. For some alarms it may be necessary to click on Standby twice.

Clicking on Return returns to the Main screen without clearing the alarm(s).

## Modes

Clicking on the Mode box on the Main screen brings up the Modes screen from where a particular mode can be invoked.




To invoke a mode click on the circle to the left of the required mode so that the dot is in that circle. Then click on OK. Alternatively double click on the mode.

Jog, Goto Position and Search bring up a further operational screen, Auto Initialise brings up a warning screen whereas Auto Continue simply commands Continue.

## Jog

The Jog screen is invoked from the Modes screen. It is used to move the antenna manually.



The double arrow button drives at high speed. Clicking on the button latches drive, clicking a second time removes drive.




The single arrow button drives at slow speed. Clicking on the button latches drive, clicking a second time removes drive.

The Pol buttons are also latching, click to start, click again to stop. The Pol buttons are only displayed if Pol has been set as available in RCM Configure.

The Beacon Level display is a real time indicator to aid peaking.

### Velocity

The Velocity screen is invoked from the Modes screen. It is used to move the antenna manually.



The antenna drive speed in degrees per second can be entered directly by clicking in the El or Az box and using the PC keyboard to enter the value. Alternatively click on the spin arrows to increase or decrease the value. Enter a positive

(unsigned) value to drive up or right and a negative value to drive down or left.

**DEMO STATION - Velocity**

Demo Sat		Beacon Level	Drive Velocity in ° per second		Return	
Freq:	1.25GHz		EI 1.27°	Az -0.55°		
Level:	-0.77dB					
EI:	29.998°					
Az:	180.005°	Drive stopped		Go	Stop	Standby
Position hold						

To commence driving the antenna at the set speed(s) click on the “Go” box. The Mode will change to “Velocity Mode”.

**DEMO STATION - Velocity**

Demo Sat		Beacon Level	Drive Velocity in ° per second		Return	
Freq:	1.25GHz		EI 1.27°	Az -0.55°		
Level:	-0.77dB					
EI:	29.998°					
Az:	180.005°	Driving		Go	Stop	Standby
Velocity mode						

The word “Driving” is displayed in green above the “Go” box when the antenna is being driven. Click on the “Stop” box to stop the antenna. The Mode changes back to “Position hold” and “Drive stopped” in red is displayed above the “Go” box.

**DEMO STATION - Velocity**

Demo Sat		Beacon Level	Drive Velocity in ° per second		Return	
Freq:	1.25GHz		EI 0.00°	Az 0.00°		
Level:	-0.77dB					
EI:	29.998°					
Az:	180.005°	Drive stopped		Go	Stop	Standby
Position hold						

Click on “Return” to exit the Velocity screen.

*Goto Position*

The Goto Position screen is invoked from the Modes screen. It is used to drive the antenna to a given position.

To command an antenna move enter the Elevation, Azimuth and Pol (where applicable) values either by clicking on the existing values and editing manually or by using the spin arrows. Click the Goto box when the values are correct.

*Auto Continue*

This Mode is invoked from the Modes screen. It commands the INTRAC to continue in Auto Mode. It is used to re-start tracking which has been interrupted for some reason but the model is still valid.

*Auto Initialise*

This Mode is invoked from the Modes screen. It clears the existing orbit model and commences learning a new one for a satellite at the current pointing.

*Search*

This Mode is invoked from the Modes screen. It is used to search a given area of sky and peak the antenna on the required satellite.

The Centre of Search co-ordinates displayed are the current co-ordinates. If it is required to search a different area enter the Elevation, Azimuth and Polarisation (if required) values. This may be done by clicking on the box and entering the values numerically or by using the spin arrows.

Set the El & Az Search Limits in a similar manner.


The dwell time is the time that the antenna is stationary between moves to allow the receiver to lock onto the beacon. The default time of 20 seconds is correct for the, optional, IBRL.

At the end of the search the INTRAC will enter either Standby or Auto-Initialise depending on the selection in the End of Search box.

When all entries are set click on the Search box to start the search. The bottom left corner of the screen will display Searching, followed By Peaking, followed by Standby or Learning.

## Function


Clicking on the Function box on the Main screen brings up the Functions screen.



To invoke a function click on the function so that the dot appears in the circle to the left of the function. Then click on the OK box. Alternatively double click on the function. Invoking the Stow function drives the antenna to the stow position and the word Stow changes to Unstow. The antenna can then be unstowed by double clicking on Unstow. Clicking on any of the other four functions brings up a further screen.

## RCM Config

Clicking on this function invokes a screen from which the RCM can be configured.



The Edit Comms Configuration allows the com port and baud rate to be set.

Edit Station Parameters is where the station name and co-ordinates are set.

Pol is set to be available or Unavailable.

The number of displayed decimal places is set.

The frequency band of the beacon receiver is set. Click on the appropriate word and then click on OK to accept the change. Click on Return.

## INTRAC Config

This screen allows the antenna stow co-ordinates, fine tune off-sets and the reserve model choice to be set.

Fine Tune Offsets are used to correct for any difference between the displayed angle and the actual pointing angle caused by an angular mounting offset in the position encoder. The Fine Tune Offsets are only set during installation or if the INTRAC or a resolver is replaced. Click on the relevant box and enter the value.

The Stow angles for El & Az may be set in a similar manner. They would normally only be set during installation.

The Reserve Model is used when and if the orbit model becomes invalid. This only happens if the tracking signal is absent for more than 72 hours. Either IESS412 or NORAD ephemeris data may be used.

When all requirements have been set click on the OK box to accept the changes.

## Stow

Selecting Stow causes the antenna to be driven to the Stow position and the stow pins to be driven in. The word Stow changes to Unstow so that once the antenna has been stowed it can be unstowed.

To cause stow or unstow either click on Stow/Unstow and then on OK or double click on Stow/Unstow.



*Limits, Time & Frequency*

This function screen allows the antenna movement soft limits to be set, the date and time to be set and the IBR-L to be tuned to the beacon frequency.

To set the Soft Limits for Azimuth, Elevation or Polarisation (if applicable) click in the appropriate box and edit the value(s). The time and/or date may be set in a similar manner. The IBR-L frequency may be set similarly or by using the spin arrows. The frequency to be set must be within the band selected in RCM Config. Clicking on OK sends the data to the INTRAC.

*Ephemeris Data*

Double clicking on Ephemeris Data brings up the Ephemeris Data, Select Satellite screen. There are further sub screens for ephemeris data which are called from this screen.

The Satellite Directory contains all the satellites associated with this RCM Antenna. Clicking on the down arrow at the right side of the box drops the list of satellites. Clicking on a satellite from the list causes that satellite's name to appear in the Satellite Name box and it's beacon frequency to appear in the IBR-L Frequency box.

The three boxes Delete, Edit and Move To operate on the satellite whose name is displayed.

Invoking Delete will erase the satellite's directory including all files. A confirmation screen is displayed before anything is erased.

Invoking Move To will bring up the Move To New Satellite screen. (see below)

Invoking Edit brings up the Edit Data screen. (see below)

#### *Valid Data Files*

The Valid Data Files section box shows the validity of files for the displayed satellite. A green tick (4) indicates valid data and a red cross (6) signifies invalid data.

#### *Nominal Position*

Nominal Position is the nominal location of the satellite. Move to Nominal Position causes the antenna to be driven to the co-ordinates and the beacon receiver to be tuned to the frequency. For a tick to be present in the Nominal Position box a file MANUAL.DAT (plus a file POLAR.DAT if polarisation drive is available) must be present, and correct, in the satellite's directory. MANUAL.DAT contains the Az & El co-ordinates of the satellite (POLAR.DAT contains the polarisation angle)

However even if there is a tick against Nominal Position the Move To box will not be available unless there is a FREQ.DAT file, with a frequency in it, in the satellite directory. This file contains the beacon frequency of the satellite.

#### *IESS412*

For a tick in the IESS412 box files REPORT.DAT and EPHEM.DAT are required in the satellite directory. REPORT.DAT contains two numbers, the pointing update time in minutes and the validity of the ephemeris data in days. EPHEM.DAT contains the IESS412 ephemeris data set which must be valid as to date range.

#### *Note*

The update time in the default file from Intelsat is 60 mins. This time is too long for INTRAC (range 0 - 59 mins). Advantech suggest a time of 10 mins is entered in REPORT.DAT.

#### *Transfer*

For a tick in the Transfer box REPORT.DAT and a valid TRANSFER.DAT file are required in the satellite directory. A TRANSFER.DAT file is created by the command "Get Transfer Data" from the Edit Data screen (see below) and is data from the INTRAC model at the time of the Get command. The data is saved in IESS412 format.

#### *NORAD*

For a tick to be present in the NORAD box a file NORAD.DAT is required in the satellite's directory. This file contains the NORAD ephemeris data which must be valid data.

*Add*

The Add box allows more satellites to be added to the antenna. Click on the box and a sub screen appears.

Click in a text box and enter the applicable text. Click on each box to be able to enter text in it. When all data is complete and correct click on OK.

A new satellite directory is created with the name given. The directory will contain the files SATNAME.DAT & FREQ.DAT . The files MANUAL.DAT (and POLAR.DAT) can be created from the edit screen. (see below)

*Delete*

Clicking on delete will delete the displayed Satellite Directory. A confirmation box will be displayed before deletion.

*Edit*


Clicking on the Edit box invokes the edit screen. This screen facilitates the editing of data files of the current satellite, copying data files from or to the current satellite, getting transfer data from the current INTRAC model and loading Transfer, IESS412 and NORAD data from valid files in the current satellite's directory.

Only the options in dark type are possible. The top three are always possible but the three load commands are only possible if valid data exists in the directory.

To invoke an option either click on the option and then click on OK or double click on the option.

*Create/Edit Data File*

This function works on the file currently displayed in the File box.

Directory:	SAT02
Satellite:	Satellite 02
File:	THIS BOX 


To edit an existing file click on the down arrow to drop the list of files, click on the file required. To create a file click in the box and type in the name of the file to create.

When the box displays the required file name double click on “Create/Edit Data File” this invokes Notepad with the selected file open. If a file is to be created a confirmation prompt is displayed before Notepad opens.

When the contents of the file are correct close Notepad and save the changes.

*Copy Ephemeris Data*

This function facilitates the copying of a file to or from the current satellite directory. The files may be copied from any other directory or drive.



Double click on “Copy Ephemeris Data”.

The current directory and it's files are shown on the left. The to and from copy command boxes are in the centre and the drive/directory list is shown on the right.

To copy a file from the sat2 directory click on the sat2 directory to drop the file list. Click on the required file and then click on the Copy File box.

**<- Copy File**

*Get Transfer Data*

Transfer data is data relating to the INTRAC orbit model which is obtained from the INTRAC by this command. The command gets the model data and stores it in IESS412 format as file TRANSFER.DAT. It can then be loaded back into the same INTRAC or into any other INTRAC.

*Note*

The INTRAC must have been in Tracking Mode for 48 hours before Transfer data can be obtained.

*Load IESS Data*

This command loads ephemeris data from the EPHEM.DAT file in the selected satellite directory into the INTRAC. This data must be valid or it will not load.

*Load Transfer Data*

This command loads ephemeris data from the TRANSFER.DAT file in the selected satellite directory into the INTRAC. This data must be valid to load.

*Load NORAD Data*

This command loads data from file NORAD.DAT in the selected satellite directory into the INTRAC. This data must be valid to load.

*Move To*

The “Move To” box on the “Ephemeris Data, Select Satellite” screen brings up the “Move to New Satellite” screen.

There are a number of options on this screen which relate to the selected

Each option requires certain data files to be present in the satellite's directory before that option can be used. Options which are not available are displayed in faint grey characters.

*Goto Nominal Position*

Selecting “Goto Nominal Position” will drive the antenna to the co-ordinates of the selected satellite. The data files required are Manual.Dat and Freq.Dat.

The other six options either generate an orbit model from ephemeris data or use such data to track using Program Track. Program Track enables tracking with no tracking signal.

If there are no valid data files in the directory the option will not be available.

#### *Generate Model from IESS Data*

The command downloads the IESS412 data to the INTRAC and instructs the INTRAC to generate an orbit model from that data and then enter Tracking Mode. The data files required are Ephem.Dat and Report.Dat.

The command downloads the IESS412 data to the INTRAC and instructs the INTRAC to Program Track from the data. The data files required are Ephem.Dat and Report.Dat.

#### *Generate Model from Transfer Data*

The command downloads the Transfer data to the INTRAC and instructs the INTRAC to generate an orbit model from that data and then enter Tracking Mode. The data files required are Transfer.Dat and Report.Dat.

#### *Transfer Program Track*

The command downloads the Transfer data to the INTRAC and instructs the INTRAC to Program Track from the data. The data files required are Transfer.Dat and Report.Dat.

#### *Generate Model from NORAD Data*

The command downloads the NORAD data to the INTRAC and instructs the INTRAC to generate an orbit model from that data and then enter Tracking Mode. The data file required is NORAD.Dat.

#### *NORAD Program Track*

The command downloads the NORAD data to the INTRAC and instructs the INTRAC to Program Track from the data. The data file required is NORAD.Dat.

#### *Standby*

Clicking on Standby from any screen will cause the INTRAC to enter Standby Mode and the RCM-4 display to return to the main screen.

#### *Return*

Clicking on Return from any screen causes the RCM-4 to return to the screen immediately before the current displayed screen. Thus continued clicking on Return will lead back to the main screen.

*The .ini file parameters*

Each parameter of the RCM.INI file is described in the Help file. Most of the parameters in the .ini file are set from within the RCM as described in this section under “Configuring the RCM”.

Described below are the parameters which can only be set in the .ini file, using a text edit package.

These parameters are :-

BeaconPolSelect  
CSOEnable  
ExtendedAz  
newNamePromptEnable

*BeaconPolSelect*

This facility requires an, optional, beacon signal switch box. The switch box can have up to four beacon inputs. Anyone of the switch box inputs can be routed to the INTRAC beacon signal input. “BeaconPolSelect” enables or disables the box switching commands.

In the .ini file BeaconPolSelect may be set to OFF, AB or ABCD. If either AB or ABCD is set a button appears next to the IBR-L Frequency box on the “Limits, Time & Frequency” screen.

DEMO STATION - Limits, Time & Frequency

Freq:	B1.5GHz	Soft Limits	INTRAC Time
Level:	0.01dB	Low EI	06-Mar-00 00:04:15 UST
EI:	29.998°	High EI	Set Date: 06-Mar-00
Az:	180.005°	Low Az	Set Time: 00:04:15
		High Az	
			IBR-L Frequency (Mhz)
			B 1500 (L-Band)
Auto [Learning]	OK	Return	Standby

Clicking on this button causes the character on it to change between A & B or to step through A, B, C & D depending on whether AB or ABCD is set in the .ini file.

Clicking on the button also causes the selection to be sent to the INTRAC where it sets an output to switch the external switchbox to route the required signal to the beacon signal input.

*CSOEnable*

See Velocity on page 122 for a description of this facility.

*ExtendedAz* A normal antenna system will only rotate through 360° but some special systems can rotate more than this. In standard configuration the azimuth software limits can only be set between 45° and 315°. For antennas which can rotate more than 360° the software limits need to be set beyond the standard settings. Setting ExtendedAz to ON allows the software limits to be set to any value from -179.999° to +539.999° as shown on the screen below.

The screenshot shows a dialog box titled "DEMO STATION - Limits, Time & Frequency". It contains several input fields and buttons. On the left, there are labels for "Freq:", "Level:", "EI:", and "Az:" with corresponding values: "B1.5GHz", "-0.10dB", "29.636°", and "180.378°". Below these is an "Auto [Learning]" button. In the center, there is a "Soft Limits" section with four input fields: "Low EI" (-4.999°), "High EI" (99.998°), "Low Az" (-179.999°), and "High Az" (539.999°). On the right, there is an "INTRAC Time" section with a date/time display showing "27-May-98 11:07:42 UST", and input fields for "Set Date:" (27-May-98) and "Set Time:" (11:07:42). Below this is an "IBR-L Frequency (Mhz)" section with a dropdown menu set to "B" and a value of "1500", with "(L-Band)" text to the right. At the bottom are three buttons: "OK", "Return", and "Standby".

*newNamePromptEnable* This function relates to the selecting of “Auto Initialise” from the Modes screen.

With this function set to OFF clicking on “Auto Initialise” causes the existing model to be cleared (a warning screen appears first). The INTRAC then enters learning mode for a satellite at the current pointing. However no information is stored about this satellite, i.e., there are no files - Satname.Dat, Freq.Dat, Manual.Dat or Polar.Dat. By setting newNamePromptEnable to ON the following screen is displayed before learning mode is entered.

The screenshot shows a dialog box titled "DEMO STATION - Auto Initialise". It contains a "Demo Sat" section on the left with labels "Freq:", "Level:", "EI:", and "Az:" and values "1.25GHz", "-14.79dB", "29.998°", and "179.720°". Below this is an "Auto [Learning]" button. In the center, there is a section titled "Either use the current name, select one from the list or create a new name" with three radio buttons: "Current", "Select", and "New". The "New" radio button is selected. To the right of the radio buttons is a "New Satellite Name" section with three input fields: "Satellite Directory:", "Satellite Name:", and "IBR-L Frequency (MHz):" (set to "1.25GHz"). At the bottom are two buttons: "Cancel" and "OK".



## **APPENDICES**

See Appendices Contents.

Deliberately left blank